

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-078530

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal 20

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 20-T25N-R9W

NMPM

12. COUNTY OR PARISH

San Juan

13. STATE

N.M.

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

M. J. Brannon

3. ADDRESS OF OPERATOR

3417 Hulen Street, Suite 124, Ft. Worth, Texas 76107

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

990'FSL, 990'FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)

6648'G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to plug and abandon this well in the following manner.

1. Set retainer at 6000' - 6050' and squeeze with 50 sacks regular cement leaving some cement on top of retainer.
2. Set 25 sacks cement plug in 4 1/2" casing from 5475' to 5120'.
3. Perforate - 3450' and set 200' (15 sacks) inside 4 1/2" casing and 200' (50 sacks) cement plugs outside of casing.
4. Perforate - 1600', set retainer at 1550' and squeeze with 30 sacks cement leaving some cement on top of retainer.
5. Perforate - 1200' and set 50 sacks cement plug in and out of 4 1/2" casing.
6. Perforate - 250' and set cement plug 150' to 250' in and out of 4 1/2" casing.
7. Set dry hole marker at surface with 10 sacks.

Verbal approval received February 23, 1981.

FOR: M. J. BRANNON

18. I hereby certify that the foregoing is true and correct

ORIGINAL SIGNED BY

SIGNED EWELL N. WALSH

Ewell N. Walsh, P. E.

(This space for Federal or State office use)

President, Walsh Engineering
& Production Corp.

TITLE

DATE 2/24/81

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

FEB 27 1981

JAMES F. SIMS
DISTRICT OIL & GAS SUPERVISOR

*See Instructions on Reverse Side

NMOCC