

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-078530

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal 20

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLE. AND
SURVEY OR AREASec. 20-T25N-R9W
NMPM

12. COUNTY OR PARISH

San Juan

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or to backfill a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

M. J. Brannon

3. ADDRESS OF OPERATOR

3417 Hulen Street, Suite 124, Ft. Worth, Texas 76107

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

990'FSL, 990'FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6648'G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was plugged and abandoned in the following manner.

1. Set retainer at 6020'. Could not pump into formation. Spotted 50 sacks of cement on top of retainer.
2. Set 25 sacks cement plug in 4 1/2" casing from 5475' to 5120'.
3. Perforate - 3450' and set 200' (15 sacks) inside 4 1/2" casing and 200' (50 sacks) cement plugs outside of casing.
4. Perforate - 1600', set retainer at 1550' and squeeze with 30 sacks cement leaving some cement on top of retainer.
5. Perforate - 1200' and set 50 sacks cement plug in and out of 4 1/2" casing.
6. Perforate - 250' and set cement plug 150' to 250' in and out of 4 1/2" casing.
7. Set dry hole marker at surface with 10 sacks.

Plug and Abandonment completed 3/25/81.

FOR: M. J. BRANNON

18. I hereby certify that the foregoing is true and correct

ORIGINAL SIGNED BY

SIGNED EWELEN N. WALSH, P.E.

President, Walsh Engineering
& Production Corp.

DATE 3/27/81

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

NMOCC

*See Instructions on Reverse Side

APPROVED
DATE
M. MILLENBACH
AREA MANAGER