<u>District I</u> - (505) 393-6161 P.O. Box 1980

Hobbs, NM 88241-1980

District II - (505) 748-1283

811 S. First
Artesia, NM 88210
<u>District III</u> - (505) 334-6178
1000 Rio Brazos Road
Aztec, NM 87410
<u>District IV</u> - (505) 827-7131

New Mexico

Energy Minerals and Natural Resources Department Oil Conservation Division

2040 South Pacheco Street Santa Fe, New Mexico 87505 (505) 827-7131 Submit: Original
Plus 2 Copies
to appropriate

District Office

Form C-139

Originated 11/1/95

APPLICATION FOR QUALIFICATION OF PRODUCTION RESTORATION PROJECT AND CERTIFICATION OF APPROVAL

THREE COPIES OF THIS APPLICATION MUST BE FILED WITH THE APPROPRIATE DISTRICT OFFICE OF THE OIL CONSERVATION DIVISION

I.	Operator:	Giant Exp	OGRID #:008987							
	Address:	P.O. Box 2	2810, Farming	gton, New Me	xico 87499					
	Contact Party:	Dia	ane Jaramillo			Phone:	(505) 326-33	325		
11.	Name of Well:		ntral Bisti Uni	it #36		API#:	30-045-0544	18		
	Location of Well Unit Letter On Township		eet from the	Sout		2310)feet fror	n the	East line, S	Section 9
HL.	Previous Produ	cing Pool N	ame:	Bisti Lower	Gallup					
IV.	Describe the pr		to return the	Well to produ	ction. (Attach ad	dditional ir	nformation if n	ecess	ary):	
V.	Date the Production		•		ced: per 16, 1995	Septembe	er 13, 1995			
VI:	Identify the Oil				now the Well ha	d thirty (3	0) days or les	s prod	uction betweer	n
VI:		3 and Decer	mber 31, 1994	4:	now the Well ha				uction betweer	n
	January 1, 1993	3 and Decer	mber 31, 1994	4:					uction between	n
	January 1, 1993	3 and Decer	mber 31, 1994 st; or	4:					uction between	n
	January 1, 1993	3 and Decer	mber 31, 1994 st; or	4:					D E (C	n 9 2 9 9 1 6 1993
	January 1, 1993 [] Ongard ina AFFIDAVIT: State of	3 and Decer active well lis New Mexic San Juan	mber 31, 1994 st; or	4: [X] OCD) ss)	Form C-115 (C				DEC M APR OUL C] [] [] [] 1 6 1996 [OM. D
VI:	January 1, 1993 [] Ongard ina AFFIDAVIT: State of County of Diane Jaramillo	3 and Decer active well lis New Mexic San Juan	nber 31, 1994 st; or co eing first duty	4: [X] OCD)) ss) / sworn, upon	Form C-115 (C	perator's	Monthly Repo	rt)	DEC M APR OUL C	1 6 1993 2011. D
	January 1, 1993 [] Ongard ina AFFIDAVIT: State of County of Diane Jaramillo 1. I am the O	New Mexico San Juan , b perator or according to the second constant of the second constant	nber 31, 1994 st; or co eing first duty	(X) OCD (X) OCD (S) SS (S) SWORN, upon	Form C-115 (C	perator's	Monthly Repo	rt)] [] [] [] 1 6 1996 [OM. D

(Title)

SUBS	CRIBED AND SWORN TO before me this 15th day of april , 19 96.
	Dawn M. Date
	Notary Public
My Co	omสแรรion Expires:
FOR C	DIL CONSERVATION DIVISION USE ONLY:
VIII.	CERTIFICATION OF APPROVAL:
	This Application for Qualification of a Production Restoration Project is hereby approved and the above referenced Well is designated as a Production Restoration Project pursuant to the "Natural Gas and Crude Oil Production Incentive Act" (Laws 1995, Chapter 15, Sections 1 through 8). By copy of the Application and Certification of Approval, the Division notifies the Secretary of the Taxation and Revenue Department of this Approval and certifies that production was restored in this Production Restoration Project on: 10 (6) 955.
	7
	District Supervisor, District
	Date: 4/20/96
IX.	DATE OF NOTIFICATION OF THE SECRETARY OF THE TAXATION AND REVENUE DEPARTMENT.
	DATE:

Giant Exploration & Production Company Workover Procedure Central Bisti Unit Well No. 36 330' FSL, 2310' FEL Section 9, T25N, R12W San Juan County, New Mexico

August 10, 1995

Purpose: To return this 5 Year Plan of Development well to production. Any casing leaks will

be repaired with a scab liner.

Pertinent Data: Please refer to the attached materials and services list, wellbore diagram, and

log sections.

Procedure:

1. Road Giant's grader to location and clean and level location and access road. Check location for anchors and replace if necessary. Deliver BOP and 210 bbl workover tank, mud pump, pit, and power swivel to location. Load the workover tank with clean produced formation water. Deliver 4900' of inspected 2-3/8" tubing to location. Move in workover unit and rig up on well.

- 2. Records indicate that there is no equipment in this well. Pick up a 6-1/4" bit and 7", 23# scraper on an inspected string of 2-3/8" tubing. Trip in the hole and tag up. If excessive fill is encountered, arrange to clean out before continuing with the procedure (PBD is 4888). Trip out of the hole with the bit and scraper.
- 3. Pick up a Retrievable Bridge Plug and full-bore Retrievable Packer and trip in the hole.

Note: Bridge plug and packer should be dressed for 7", 23# casing (casing is 20# and 23#). It is estimated that 23# casing exists from TD up to 4226' and 20# casing exists from 4226' up to the surface. The top joint of casing is 23#.

- 4. Set RBP at about 4700'. Pull up and set the packer just above the RBP and use the mud pump to pressure test the bridge plug to 1000 psi for 5 minutes to make sure that the RBP is sealing properly.
- 5. Pull the full-bore packer to about 4300' and pressure test below the packer to 1000 psi. If pressure fails to hold, move the packer downhole to find the lowest possible hole in the casing. The cement top in this well is estimated at 4400'.
- 6. If no leak is encountered, leave the RBP. Pull the full-bore packer uphole and continue to pressure test. If one hole is found, pull the packer up to 1500' and begin to test while moving down the hole. Attempt to find the top and bottom of the entire leaking interval. Trip out of the hole with the bridge plug and packer. Trip back in the hole with the packer and a seating nipple on the 2-3/8" tubing string. Set the packer at approximately 4700'.
- 7. Begin swab testing the perforations. Attempt to swab back fines and debris out of the perforations and pull the fluid level down so that a minimal amount of fluid is bullheaded into the perforations. Continue swabbing until the returns clean up.
- 8. Rig up BJ Services Company to acidize the Gallup perforations with 1000 gal 15% HCl acid containing 2 gal/1000 I-22 (inhibitor), 5 gal/1000 Citric acid (iron control), 1 gal/1000 Nine-40 (surfactant), 1 gal/1000 Clay Master-5 (clay control), and 1 gal/1000 LT-21 (silt suspender/surfactant). Acid procedure is as follows:

Giant Exploration & Production Company Workover Procedure Central Bisti Unit Well No. 36

- a. With the packer set at 4700', swab the fluid level down in the tubing. Pump the 1000 gal of acid to spot the acid across the Lower Gallup perforations. Shut down pumping and allow the acid to soak on the perforations for approximately 15 minutes.
- b. Begin displacing the acid with clean produced Gallup water. Underdisplace the acid with 17 bbl of clean produced Gallup water. Once on displacement, attempt to maximize the pump rate while staying under 1000 psi. Shut down pumping and monitor the pressure.
- c. If the well is on a vacuum, leave the tubing open to the atmosphere until the vacuum stops and shut the well in. If the well still has pressure after pumping the 17 bbls of displacement, continue displacing the acid with 8.5 additional bbls of water. Shut down pumping and shut the well in. Obtain ISIP, 5 min., 10 min., and 15 min. shut-in pressures.
- 9. Leave the well shut in and allow the acid to soak on the formation for approximately (1) hour. Rig up to begin swabbing back the acid load. Attempt to swab back all acid if possible. Continue swabbing to ensure the returns clean up and are free of fines.
- 10. Release the packer after swab testing and trip out of the hole. Pick up and trip in the hole with a 4-1/2", 9.5# scab liner and isolating packers on the 2-3/8" tubing string with an on/off tool. Set the liner across the leaking interval of casing and trip out of the hole with the 2-3/8" tubing string.
- 11. Trip back in the hole with the open-ended 2-3/8" tubing string. Tag up fill and arrange to clean out by swabbing or circulating the hole clean. Trip out of the hole with the tubing string.
- 12. Trip back in the hole with the production tubing string. The production string should consist of (1) joint 2-3/8" tailpipe (set at or below the bottom perforation at 4881'), perf sub, seating nipple, 2-3/8" tubing to the top of the liner, 2-3/8" x 7", 20# tubing anchor, and remaining 2-3/8" tubing string. Set the anchor and land the tubing in the wellhead slips after nippling down the BOP. Run enough pipe above the top packer so the anchor will not hit the top packer when tagging up PBD.
- 13. Trip in the hole with a 2" x 1-1/2" x 16' rod pump on a 3/4" rod string. Seat the pump and hang rod string. Check pump action.
- 14. Deliver a 114 or 160 pumping unit to location and set the pumping unit on a concrete pad. Install a gas engine on the pumping unit.
- 15. Pressure test the existing flowline from the wellhead to the flowline manifold. If severe corrosion is present on the line, it may need to be replaced. If a small hole is present, patch the hole and continue pressure testing to ensure the line's integrity.
- 16. Obtain a well test once the well stabilizes. Shoot and monitor the fluid level to keep the well in a pumped off condition.
- 17. Clean and organize location. Return all unused materials to the CBU Yard.

Giant Exploration & Production Company Workover Procedure Central Bisti Unit Well No. 36

AFE Number: 5NDR04072

Prepared by: Paul R. Williams

Approved by: Jeffrey R. Vaughan

AFE Approval Date: 8/17/95

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No. 14-20-603-1228

BUREAU ()F LAND MAN	NAGEMENT: ABT 10 DM 2.	6. If Indian, Allottee or Tribe Name				
SUNDRY NOTIC	CES AND REP	ORTS ON WELLS					
Do not use this form for proposals	7. If Unit or CA. Agreement Designation						
Use "APPLICATIO	ON FOR PERMIT-	-" for such prophsals it. a Civi	1,1141				
SUBMIT	IN TRIPLICATE		Central Bisti Unit				
1. Type of Well X Oil Well Gas	s Well	Other	8. Well Name and No. Central Bisti Unit Well No. 36				
2. Name of Operator	, ,, e.i		9. API Well No.				
Giant Exploration & Production	30-045-05448						
3. Address and Telephone No.			10. Field and Pool, or Exploratory Area				
P.O. Box 2810, Farmington, Ne	Bisti Lower Gallup						
4. Location of Well (Footage, Sec., T., R., I	11. County or Parish, State						
	330' FSL, 2310' FEL, Sec. 9, T25N, R12W						
	O INDICATE N	ATURE OF NOTICE, REPORT, OR (San Juan, New Mexico OTHER DATA				
TYPE OF SUBMISSION		TYPE OF ACTION					
		Abandonment	Change of Plans				
Notice of Intent	Щ	Recompletion	New Construction				
	لِيا	Plugging Back	Non-Routine Fracturing				
X Subsequent Report	<u></u> _	Casing Repair	Water Shut-Off				
Final Abandanasa Nation		Altering Casing	Conversion to Injection				
Final Abandonment Notice	X	Other Return to Production	Dispose Water (Note: Report results of multiple completion on Well				
			Completion or Recompletion Report and Log form.)				
 Cleaned out to 4900'. Pressure tested casing. F Acidized existing perforagal. acid. Installed 4-1/2" liner with Installed production tubin Installed pumping unit. This well had first production 	tion Company round leaks from the found leaks from	returned the subject well to produc n 1353' to 3726'. '', 4787'-4801', 4806'-24', 4831'-41	tion as follows:				
14. I hereby certify that the foregoing is true		Anna Enginean	D				
Paul R. Williams	little	Area Engineer	Date OCT 1 8 1995				
(This space for Federal or State office Approved by	Date						
Conditions of approval, if any:	Duc						
·· · ·							

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any manner within its jurisdiction. ACCEPTED FOR RECORD

*See Instruction on Reverse Side

15 2 h 1995

FARMINGTON DISTRICT OFFICE