

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION P. O. BOX 2088 SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-2827-6	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
Name of Operator El Paso Natural Gas Company		8. Farm or Lease Name San Juan 28-7 Unit
Address of Operator P.O. Box 4289, Farmington, New Mexico 87499-4289		9. Well No. 172 (PC-CH)
Location of Well UNIT LETTER <u>K</u> <u>1590</u> FEET FROM THE <u>South</u> LINE AND <u>1560'</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>27N</u> RANGE <u>7W</u> NMPM.		10. Field and Pool, or Wildcat So. Blanco PC-Under Chacra
15. Elevation (Show whether DF, RT, SR, etc.) 6591' GL		12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPERATIONS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set 57 sack cement plug in Chacra from 2100'-4169'. (Chacra top @ 4018' - PC top @ 3040' - Ojo Alamo top @ 2162')
- 2) Set 35 sack cement plug in ^{CSC}PC from 1950'-3232'.
- 3) Set 5 sack cement plug in ^{CSC}PC from 176' to surface.
- 4) Perforated ^{CSC}CH @ 176' and circulated 85 sacks cement to surface.
- 5) Set dry hole marker.

RECEIVED
JUN 18 1984
OIL CON. DIV.
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Douglas W. Mussett TITLE Production Engineer DATE June 15, 1984

Original Signed by CHARLES GHOLSON

APPROVED BY _____ DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE APR 10 1985

CONDITIONS OF APPROVAL, IF ANY: