

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on reverse side)

Form approved,
Budget Bureau No. 42 R1424
5. LEASE DESIGNATION AND SERIAL NO.
NM 04226
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR El Paso Natural Gas Company		8. FARM OR LEASE NAME McManus
3. ADDRESS OF OPERATOR PO Box 990, Farmington, NM 87401		9. WELL NO. 7
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1404'S, 1142'East		10. FIELD AND POOL, OR WILDCAT Ballard Pictured Cliffs
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 31, T-26-N, R-8-W NMPM
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6408'GL		12. COUNTY OR PARISH San Juan
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:


WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

(NOTE: Report results of multiple completion on well Completion or Recompletion Report and Log form.)



17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

It is intended to plug and abandon the subject well in the following manner

Spot a 25 sk. cement plug in the open hole section to cover to 1920' (top of Pictured Cliffs at 2022').

Determine the free point of the 5 1/2" casing by stretch method. If free point is below base of the Ojo Alamo (1372'), shoot off above the free point and recover casing.

Spot a sufficient cement plug on the casing stub to cover back to the base of the Ojo Alamo formation.

If free point is found above the base of the Ojo Alamo formation, perforate squeeze holes at 1372'. Spot a 45 sk. cement plug across the squeeze holes and pressure displace 20 sks. into the formation (fill inside casing from 1172-1372').

Shoot off casing above the free point and recover casing. Spot a 60 sk. cement plug in the 7 7/8" open hole on the casing stub. (200' cement plug)

Spot a 30 sk. cement plug in the 7 7/8" open hole below the base of the surface casing at approximately 200' (100' cement plug).

Place a 10 sk. cement plug at the surface, install a dry hole marker and clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED

L.A. James

TITLE

Sr. Drilling Engineer

DATE

9-9-76

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: