

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>El Paso Natural Gas Company</b> 3. Address of Operator <b>Box 990, Farmington, New Mexico 87401</b> 4. Location of Well UNIT LETTER <b>L</b> <b>1480</b> FEET FROM THE <b>South</b> LINE AND <b>790</b> FEET FROM <b>West</b> LINE, SECTION <b>30</b> TOWNSHIP <b>26N</b> RANGE <b>8W</b> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) <b>6259' GL</b>	5a. Indicate Type of Lease State <input type="checkbox"/> <b>Indian</b> Fee <input type="checkbox"/> 5. State Oil & Gas Lease No. 7. Unit Agreement Name 8. Farm or Lease Name <b>Whan Jones</b> 9. Well No. <b>2 (P&amp;A)</b> 10. Field and Pool, or Wildcat <b>Basin Dakota</b> 12. County <b>San Juan</b>
--	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well in the following manner:


Kill well and spot 50 sacks of cement on the bottom.

Ojo Alamo was protected from contamination during primary cement job.

Determine free point. Cut off 4 1/2", 10.5# casing, spot 30 sack cement plug on casing stub, pull casing.

Spot 30 sack cement plug across surface casing shoe.

Place 10 sack plug at surface and install a dry hole marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed F. H. WOOD

TITLE Petroleum Engineer

DATE 7-21-70

APPROVED BY [Signature]

TITLE SUPERVISOR DIST. #3

DATE JUL 23 1970

CONDITIONS OF APPROVAL, IF ANY: