Form 9-331 (May 1963)

16.

UNITED STATES

SUBMIT IN TRIPLICATE* DIOD (Other Instructions on re-

Budget Bureau No. 42 R1424

DEPAR	GEOLOGICAL SURVEY	SF 078103
(Do not use this form for pro	DTICES AND REPORTS ON WELLS posals to drill or to deepen or plug back to a different reservoir. CATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
1.		7. UNIT AGREEMENT NAME
WELL GAS WELL X OTHER		Huerfano Unit
2. NAME OF OPERATOR	7	8. FARM OR LEASE NAME
El Paso Natural	Gas Company	Huerfano Unit
3. ADDRESS OF OPERATOR		9. WELL NO.
PO Box 990, Farm	nington, NM 87401	57
4. LOCATION OF WELL (Report location	n clearly and in accordance with any State requirements.	10, FIELD AND POOL, OR WILDCAT
At surface	L750's, 990'W \ \	Ballard Pic.Cliffs
•		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
	The same of the sa	Sec. 26, T-26-N, R-9-W
·		NMPM
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH 13. STATE
	6456'GL	San Juan NM

NOTI	CE O	F INTENTION TO:	SUBSEQUENT	REPORT OF:	
T WATER SHUT-OFF		PULL OR ALTER CASING	WATER SHUT-OFF	REPAIRING WELL	_
COULDE DE LOS		MULTIPLE COMPLETE	EDACTURE TREATMENT	ALTERING CASING	

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

	 	L			1	
TEST WATER SHUT-OFF	 PULL OR ALTER CASING		WATER SHUT-OFF		REPAIRING WELL	_
FRACTURE TREAT	 MULTIPLE COMPLETE		FRACTURE TREATMENT		ALTERING CASING	_
SHOOT OR ACIDIZE	 ABANDON*	X	SHOOTING OR ACIDIZING		ABANDONMENT*	_
REPAIR WELL	CHANGE PLANS				f multiple completion on Well	_
(Other)			Completion or Reco	omple	of multiple completion on Well- tion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is intended to plug and abandon the subject well in the following manner:

Rig up, kill well, circulate the hole.

Spot a 45 sk. cement plug across the perforated interval (2026-35'). Pressure displace 20 sks. of cement through the perforations. Plug fills 5 1/2" casing to 1717'.

Spot a 25 sk. cement plug at the base of the Ojo Alamo (1328') Pull tubing. to fill to 1110'.

Determine the free point of the $5 \frac{1}{2}$ " casing by stretch method. Shoot off casing above the free point and recover.

Spot a 60 sk. cement plug in the open hole section on the casing stub to fill 207' above the casing stub.

Spot a 60 sk. cement plug in the open hole section below the base of the surface casing to fill 207' of open hole.

Place a 10 sk. cement plug at the surface, install a dry hole marker and clean up location.

signed AHIMA		Sr.Drilling	Engineer	DATE 9-15-76	
This space for Federal or State office use)					
PPROVED BYONDITIONS OF APPROVAL, IF ANY:	TITLE		GEP 16 1976		
Olas				and the state of t	

*See Instructions on Reverse Side