

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	Huerfano Unit
3. Address of Operator	8. Farm or Lease Name
El Paso Natural Gas Company	Huerfano Unit
Box 990, Farmington, New Mexico	9. Well No.
4. Location of Well	2
UNIT LETTER J, 1988 FEET FROM THE South LINE AND 1980 FEET FROM	10. Field and Pool, or Wildcat
THE East LINE, SECTION 25 TOWNSHIP 26N RANGE 10W NMPM.	Undesignated P. C.
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
6530' GL	San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Due to non-commercial production and to non-economical workover conditions it is intended to plug and abandon this well in the following manner:

Spot 50 sack cement plug down the tubing from 1855' to 2075'.

Determine free point of 7" casing. If there is enough casing free to be economical to recover, shoot off casing at the free point.

If casing is shot off, spot 30 sack cement plug on casing stub. Pull casing.

Put 10 sack cement plug in top of surface casing and install 4" x 4' permanent plug and abandonment marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Oilman Signed by  
Carl A. Matthews

SIGNED TITLE Petroleum Engineer

DATE 10-4-66

APPROVED BY SUPERVISOR DIST. #3

DATE OCT - 5 1966

CONDITIONS OF APPROVAL, IF ANY: