UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

	ports on Wells		
	<u>.</u>		
		5.	Lease Number
l. Type of Well	L	6.	SF-078388 If Indian, All.
GAS		0.	Tribe Name
2. Name of Operator		7.	Unit Agreement N Huerfanito Unit
PITEL INCTON			
RESOURCES OIL & GAS COMPA	NTV		
OIL & GAD COMPA	411	8.	Well Name & Numb
. Address & Phone No. of Operator	·. <u>-</u>	.	Huerfanito Unit
PO Box 4289, Farmington, NM 87499 (505) 326-9700		9.	
			30-045-05963
4. Location of Well, Footage, Sec., T, R, M 990' FNL, 1800' FEL, Sec.12, T-26-N, R-9-W, NMPM		10.	Field and Pool
			Basin Dakota
		11.	County and State
			San Juan Co, NM
	ing Casing - Tubing repai		o Injection
13. Describe Proposed or Completed Operat	tions		
It is intended to repair the tubing of attached procedure.	on the subject		
	DECEI MAY 1 3 OIL CON	VED 1998 . DIV.	ng to the
4. I hereby certify that the foregoing :	OIL CON DIST.	VED 1938 DIV.	ng to the
34. I hereby certify that the foregoing of the state of t	OLL CON	VED 1998 DIV. 3	ate 5/12/98

Huerfanito Unit No. 91

Basin Dakota Field 990' FNL, 1800'FEL

Unit B, Section 12, T-26-N, R-09-W

Latitude / Longitude: 36° 30.42' / 107° 44.26'

DPNO: 30056

Tubing Repair Procedure

Project Summary: The Huerfanito Unit No. 91 is a Dakota producer drilled in 1965. The tubing in this well has not been pulled since 1965. The well currently is producing 62 mcf/d and is experiencing liquid loading. We propose to pull and inspect the tubing, install a plunger lift system and return the well to production.

- Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental 1. regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well 2. down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- Release donut and pick up additional joints of tubing and tag bottom. (Record depth.) TOOH with 3. tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If casing requires clean out, TIH with bit and bit sub and CO to PBTD prior to running casing 4. scraper. Roundtrip casing scraper and bit to below perforations. (Do not clean out with casing scraper.) PU above perforations and flow the well naturally, making short trips for clean up when necessary. TOOH.
- TIH with 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off 5. bottom. Rabbit all tubing.
- Land tubing near 6555'. ND BOP and NU wellhead. Pump off expendable check. Obtain final 6. pitot gauge up the tubing. If well will not flow on it's own, make swab run to seating nipple. If a swab run is not necessary, run a broach on slickline to ensure that the tubing is clear. RD and MOL. Return well to production.

Recommended: 2 Midlig 4/9/98
Operations Engineer

Approved:

Kevin Midkiff Office - (326-9807)

Pager - (564-1653)

Production Foreman Office - (326-9560)

Steve Florez

Pager- (327-8346)