Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED Budget Bureau No. 1004-0135

Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.		5. Lease Designation and Serial No.
		0 92 078476
		6. If Indian, Allottee or Tribe Name
Use "APPLICATION FO	PR PERMIT—" for such proposals	
CUDMI	IN TOID IOATE	7. If Unit or CA, Agreement Designation
	TIN TRIPLICATE	
1. Type of Well Gas Other		0xnard 8. Well Name and No.
Well Well Other 2. Name of Operator		6. Well Name and No.
Conoco. Inc.		9. API Well No.
3. Address and Telephone No.		30-045-20631
10 Desta Dr. Ste 100W, Midland, TX 79705 (915) 686-6548 4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		10. Field and Pool, or Exploratory Area
•	ожетраюц)	11. County or Parish, State
820' FSL & 1040' FEL Sec. 11, T-27N, R-8W		San Juan
3ec. 11, 1-2/N, R-0W		Sali Juan
12. CHECK APPROPRIATE BOX	s) TO INDICATE NATURE OF NOTICE, REPOR	RT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
Notice of Intent	Abandonment	Change of Plans
	Recompletion	New Construction
Subsequent Report	Plugging Back	Non-Routine Fracturing
Final Abandonment Notice	Casing Repair	Water Shut-Off
	Altering Casing Other	Conversion to Injection Dispose Water
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
This well will be P&A'd accord	DECENTION MAY 3 0 1995 OUL CON. DIV.	RECEIVED BLM 95 KAY 22 PH 2: 53
14. I hereby ceptly that the foregoing is tool and correct Signed	Title Sr. Conservation Coordinat Title	or Date 5/19/95 PPROVED
Title 18 U.S.C. Section 1001, makes it a crime for any person	knowingly and willfully to make to any department or agency of the litting	thes any false, fictitious or fraudulent statements
or representations as to any matter within its jurisdiction.		ET ZICT MANAGED

RECEIVED BLM


95 KAY 22 Ph 2: 51,

Oxnard #2

Current

South Blanco Pictured Cliffs

CO FARM NOTON, NEW SE Section 11, T-27-N, R-8-W, San Juan County, NM



7-7/8" Hole

TD 3073'

4-1/2" 9.5# K-55 set @ 3073' Cmt w/ 149 cf

Oxnard #2 So. Blanco Pictured Cliffs SE Section 11, T-27-N, R-8-W San Juan County, New Mexico

Note: All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures.

- 1. Install and test location rig anchors. Prepare blow pit. Comply to all NMOCD, BLM, and Conoco safety regulations.
- MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with water as necessary. ND wellhead and NU BOP. Test BOP.
- 3. POH and tally 1-1/4" EUE tubing (2957'). Visually inspect (tubing may have hole, depth unknown), if necessary LD and PU 2" tubing workstring.
- 4. Plug #1 (Pictured Cliffs perforations and Fruitland top, 2990' 2702'): RIH with open ended tubing to 3040' or as deep as possible. Pump 25 bls water down tubing. Mix 40 sxs Class B cement (50% excess, long plug) from 3040' to 2702' to cover Pictured Cliffs perfs and Fruitland top. POH to 1800' and WOC. RIH and tag cement. Load well with water and circulate clean. Pressure test casing to 500#. POH with tubing.
- 5. Plug #2 (Kirtland and Ojo Alamo tops, 2274' 2068'): Perforate 4 squeeze holes at 2274'. Establish rate into squeeze holes if casing tested. PU 4-1/2" cement retainer and RIH; set retainer at 2224'. Pressure test tubing to 1000#; establish rate into squeeze holes. Mix and pump 114 sxs Class B cement, squeeze 94 sxs outside casing from 2274' to 2068' and leave 20 sxs inside 4-1/2" casing to cover Kirtland and Ojo Alamo tops. POH with tubing and LD setting tool. Pressure test casing to 500#.
- 6. Plug #3 (Nacimiento, 1008' 908'): Perforate 4 squeeze holes at 1008'. Establish rate into squeeze holes if casing tested. PU 4-1/2" cement retainer and RIH; set at 958'. Establish rate into Nacimiento squeeze holes. Mix 51 sxs Class B cement, squeeze 39 sxs cement outside 4-1/2" casing from 1008' to 908' and leave 12 sxs cement inside casing to cover Nacimiento top. POH and LD tubing and setting tool
- 7. Plug #4 (Surface): Perforate 2 squeeze holes at 155'. Establish circulation out bradenhead valve. Mix and pump 44 sxs Class B cement from 155' to surface, circulate good cement out bradenhead valve. Shut in well and WOC.
- 8. ND BOP and cut off wellhead below surface casing. Install P&A marker with cement to comply with regulations. RD, MOL, cut off anchors, and restore location.

RECEIVED

Surviging Bank Cont.

95 MAY 22 PH 2: 54

070 FARMINGTON, 101

Today's Date: 3/31/95 Spud: 4/27/70 Completed: 6/5/70

Nacimiento @ 958

Ojo Alamo @ 2118'


Kirtland @ 2224'

Fruitland @ 2752

Oxnard #2 Proposed P&A

South Blanco Pictured Cliffs

SE Section 11, T-27-N, R-8-W, San Juan County, NM



7-7/8" Hole

TD 3073'

22324

4-1/2" 9.5# K-55 set @ 3073' Cmt w/ 149 cf