4. LICATION OF WELL (Report location clearly and in accordance with any state requirement.  See also space 17 below.)  At surface  990' FNL & 1190' FEL  15. ELEVATIONS (Show whether DF, RT, GR, etc.)  6187 GL  16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  TEST WATER SHUT-OFF  PULL OR ALTER CASING  MULTIPLE COMPLETE  WATER SHUT-OFF  FRACTURE TREAT  MULTIPLE COMPLETE  FRACTURE TREATMENT  WAY Pic 11. SEC., T., Surviv.  Subsequent Report  X  FRACTURE TREATMENT	OF: REPAIRING WELL ALTERING CASING ABANDONMENT*
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other)  17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including est proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for	OF: REPAIRING WELL ALTERING CASING ABANDONMENT*
Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other)  17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including est proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for	OF: REPAIRING WELL ALTERING CASING ABANDONMENT*
TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF X  FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT SHOOT OR ACIDIZE ABANDON*  REPAIR WELL CHANGE PLANS (Other)  17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including est proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for	REPAIRING WELL  ALTERING CASING ABANDONMENT*
TEST WATER SHUT-OFF  FRACTURE TREAT  SHOOT OR ACIDIZE  REPAIR WELL  (Other)  TO DESCRIBE PROPOSED OR COMPLETE OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including est proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for	REPAIRING WELL  ALTERING CASING ABANDONMENT®
Move in - rig up rotary tools. Spud at 4:45 p.m. 5-11-77. Drille hole to 51 feet. Ran one joint 8 5/8 20# J & L casing and set at 49 for Cemented with 40 sacks class "B" plus 2% CaCL2. Circulated cement ret Plug down at 6:25 p.m. 5-11-77. Wait on cement.	timated date of starting new all markers and zones perti- ed 11" eet.
RECE	IVED
MAY 1	6 1977
U. S. GEOLOGI ERPMINGTO	ICAL SURVEY
18. I hereby certify that the foregoing is true and correct  Agent  DAT	5-12 <b>-</b> 77
SIGNED William T Jones TITLE DAT	