

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Amoco Production Company Attn: John Hampton

3. Address and Telephone No.

P.O. Box 800 Denver, Colorado 80201

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 15 T28N R7W 1850' FSL and 890' FWL

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

079289-A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

San Juan 28-7 Unit 75

9. API Well No.

30-039-07412

10. Field and Pool, or Exploratory Area

S. Blanco/Blanco MV

11. County or Parish, State

Rio Arriba, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Pumping Unit will

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Please see attachment for procedures.

RECEIVED
DEC 27 1991
OIL CON. DIV
DIST. 3

If you have any questions please contact Cindy Burton @ (303) 830-5119.

DEC 26 1991

14. I hereby certify that the foregoing is true and correct

Signed

John Hampton AB

Title Sr. Staff Admin. Supv.

Date

12/17/91

(This space for Federal or State office use)

MAJCCD

San Juan 28-7 Unit #75
NW/4 SW/4 Section 15 T28M R7W
Rio Arriba County, New Mexico

- 1) MIRUSU. Blow well down. Kill well with 2% KCl water if necessary. NDWH. NUBOPs.
- 2) Pull rods x pump, laying down rods. Report any significant scale buildup on the morning report and catch scale sample, if possible. TIH with tubing x tag bottom. TOH with tubing. Visually inspect and replace bad joints.
- 3) If fill was found in step #2, TIH with bailer and clean out fill. TOH.
- 4) TIH with 2-3/8" tubing with a seating nipple one joint off bottom. Hydrotest tubing into hole. Land tubing @ 5170'. Swab well in if necessary.
- 5) Drop bumper spring bottom hole assembly and put well on production using plunger lift. Discuss plunger installation with John Hatch.
- 6) Move pumping unit, rods and pump back to town.

Note: All depths relative to drillers KB, which was 10' above ground level.

Report major problems to Eric Root
Work (303) 830-6016
Home (303) 699-2583

SJ 28-7 UNIT 075 2005
LOCATION - L15- 28N- 7W
DUAL PC-MV
ORIG.COMPLETION - 6/57
LAST FILE UPDATE - 12/91 BY CSW

