

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

<p>1. Type of Well GAS</p> <p>2. Name of Operator BURLINGTON RESOURCES OIL & GAS COMPANY</p> <p>3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700</p> <p>4. Location of Well, Footage, Sec., T, R, M 1470' FSL, 1840' FWL, Sec.13, T-28-N, R-5-W, NMPM</p>	<p>5. Lease Number SF-080516-B</p> <p>6. If Indian, All. or Tribe Name</p> <p>7. Unit Agreement Name San Juan 28-5 Unit</p> <p>8. Well Name & Number San Juan 28-5 U #101</p> <p>9. API Well No. 30-039-21804</p> <p>10. Field and Pool Basin Dakota</p> <p>11. County and State Rio Arriba Co, NM</p>
---	--

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action	
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other - Tubing Repair	

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed Wayne Townsen Title Regulatory Administrator Date 9/10/99
trc

(This space for Federal or State Office use)

APPROVED BY WAYNE TOWNSEN Title A.T.L. Date 9-16-99
CONDITION OF APPROVAL, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.


NMOCD

San Juan 28-5 Unit #101
Basin Dakota
Unit K, Sec. 13, T-28-N, R-05-W
Latitude / Longitude: 36° 39.46836' / 107° 18.76464'
Recommended Tubing Repair Procedure 9/1/99

Project Justification: The tubing in the San Juan 28-5 Unit #101 has not been pulled since its completion in 1978. An examination of the well's rate/time performance revealed that the well has been producing with a decline of approximately 3.4% per year. This shallow decline is believed to be caused by sandfill that was discovered in the tubing during an August 1999 slickline run.

NOTE: ALL DEPTHS ARE MEASURED FROM KB. KB to GL was 10'.

1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Prior to moving in rig, make one-call and then verify rig anchors and dig pit.
2. MIRU workover rig. NU relief line and blow well down (kill with 2% KCL water only if necessary). ND WH and NU BOP. Test and record operation of BOP rams. Replace any WH valves that do not operate properly. Test secondary seal and install or replace if necessary. **NOTE: Have wellhead serviced and prepared for a 2-3/8" tubing string.**
3. Dakota, 1-1/2", 2.9#, J-55 tubing set at **8871'**. Broach tubing and set tubing plug in tubing at **8650'**. Release donut, pick up additional joints of tubing and tag bottom, recording the depth. PBTD should be at +/- **8895'**. TOOH and LD 1-1/2" tubing. Visually inspect tubing for scale and corrosion, and notify Operations Engineer and Drilling Superintendent if they are present.
4. PU 3-7/8" bit and bit sub on 2-3/8", 4.7#, J-55 tubing and round trip to PBTD, cleaning out with air/mist. **NOTE: When using air/mist, mist rate must not be less than 12 bph.** Speak with Operations Engineer and Drilling Superintendent, and if necessary, determine the best way to remove scale from the casing and perforations.
5. TIH with one 4' pup joint of 2-3/8" tubing with expendable check, seating nipple (above pup joint), then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to ensure that the tubing is clear. TIH with remaining 2-3/8" tubing. Replace any bad joints. CO to PBTD with air/mist.
6. PU above the top Dakota perforation at **8717'** and flow the well naturally, making short trips for clean-up when necessary. Discuss sand production with Operations Engineer and Drilling Superintendent to determine when clean-up is sufficient.
7. Land tubing at **8825'**. Obtain pitot gauge from casing and report this gauge. Broach the upper 1/2 of the production tubing. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to ensure that expendable check has pumped off. If well will not flow on its own, make swab run to SN. RD and MOL. Return well to production.

Recommended: 
Operations Engineer 9/1/99

Approved:  9/8
Drilling Superintendent

Operations Engineer: L. Tom Loveland

Office 326-9771
Pager 324-2568
Home 564-4418