

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
3. Address of Operator		9. Well No.
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>G</u> , <u>1610</u> FEET FROM THE <u>North</u> LINE AND <u>1460</u> FEET FROM		12. County
THE <u>East</u> LINE, SECTION <u>21</u> TOWNSHIP <u>28N</u> RANGE <u>5W</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		
6722' GL		

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was drilled to 8057' with gas, water was encountered at total depth. Logging tools (gamma ray-induction) were lost at 6128' with approximately 500' of wireline on top. Washover pipe was stuck at 5768' during fishing operations.

Due to the above junk in the hole it is intended to plug and abandon this hole as set out below, and sidetrack junk and drill a new deviated hole to approximately 8050':

Spot a 100 sack cement plug on top of the junk at 6120' to cover to 5670'.

Set a drillable cement retainer near the bottom of the 7" casing and squeeze the open hole with 200 sacks of cement with 1/4 cu. ft. of Gilsonite and 2% gel, followed by 100 sacks of cement with 10% sand and 2% calcium chloride.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
Carl E. Matthews

TITLE Petroleum Engineer

DATE 8-26-68

APPROVED BY

Ernest C. Arnold

TITLE

Sup Dist III

DATE

8-27-68

CONDITIONS OF APPROVAL, IF ANY: