

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B 11125.49	


## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Brookhaven Com C
3. Address of Operator P. O. Box 990, Farmington, New Mexico 87401	9. Well No. 4
4. Location of Well UNIT LETTER <u>L</u> , <u>1700</u> FEET FROM THE <u>south</u> LINE AND <u>840</u> FEET FROM THE <u>west</u> LINE, SECTION <u>36</u> TOWNSHIP <u>27N</u> RANGE <u>8W</u> N.M.P.M.	10. Field and Pool, or Wildcat So. Blanco P.C.
15. Elevation (Show whether DF, RT, GR, etc.) 6225' GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Purpose to abandon the subject well in the following manner:  
Squeeze open hole section with 21 sx of cement. Cement plug (2200 to 2400' 25 cu. ft.).  
Perforate squeeze hole at 1469'. Spot 33 sx (39 cu. ft.) Cement plug across perforation and squeeze cement through perforation leaving a 100' cement plug (1369 to 1469) in casing to cover Ojo Alamo.  
Perforate squeeze hole 150' below base of the surface casing @ 290'. Spot 90 sx (106 cu. ft.) cement plug across perforation. Squeeze cement into perforation to fill the annulus between production and surface casing and leave a cement plug inside production casing from 83 to 290'.  
Spot a 10 sx (12 cu. ft.) cement plug at surface and install P & A marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Loren W. Fethergill TITLE Production Engineer DATE 2-27-79  
APPROVED BY AR. [Signature] TITLE SUPERVISOR DATE FEB 28 1979

CONDITIONS OF APPROVAL, IF ANY:

Notify this office or me personally 48 hours prior to field operations.