- 1. 5-1/2" casing will not be pulled from well.
- 2. Squeeze and cover perforations with 25 sacks
- 3. Perforate 5-1/2" at bottom of Ojo Alamo (1578') and squeeze with 35 sacks.
- 4. If no breakdown, spot 50' plug across perforations (6 sacks) and perforate at 1200' and squeeze with 35 sacks.
- 5. Surface Plug 180' to surface (25 sacks)
- 6. Location will be cleaned up and reseeded.

FOR: R & G DRILLING COMPANY	DIST. 3
18. I hereby certify that the foregoing is true and correct  WALSH ENGINEERING & PROD.  CORPORATION  Blancett, Production Foreman	DATE 12/14/79
(This space for Federal or State office use)	

APPROVED BY \_\_\_\_\_\_CONDITIONS OF APPROVAL, IF ANY:

TITLE

NMOCC

\*See Instructions on Reverse Side

DEC 2 0 1979

ACTING DISTAIL; ENGINEER

Olcal