

FD-204 (May 1963)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

(Other instructions on reverse side)

Budget Bureau No. 42-81424

5. LEASE DESIGNATION AND SERIAL NO.

NM-03523

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Holloway "B" Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

31-27N-11W

MM

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Beta Development Co.

3. ADDRESS OF OPERATOR

125 Petroleum Plaza Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

1850/S 790/E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6103' C.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

3-16-77

Rig up F & A rig, trip tubing lay 11 jt's with holes down, sting back into Model "D" production packer @ 6153' pump 50 sacks cement into Dakota formation, pick up out of packer spot 30 sacks on top of Model "D" packer @ 6153', spot 40 sacks cement @ 5500', pick up on casing, casing into @ 3220' lay casing down, trip in with tubing, spot 60 sacks cement 50' in and 150' out of casing stub @ 3220', spot 60 sacks cement @ 1865', spot 60 sacks cement plug @ 700' 15 sacks @ 325' pump 15 sacks cement in top of surface pipe, dug up all flow lines, cut surface pipe off 4' below ground level, released rig 3-21-77.



APR 7 1977

U. S. GEOLOGICAL SURVEY

18. I hereby certify that the foregoing is true and correct

Original signed by:

SIGNED D. E. BAXTER

TITLE Superintendent

DATE 4-4-77

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

1721000