

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well ☐ gas ☒ well ☐ other ☐

2. NAME OF OPERATOR  
El Paso Natural Gas Company

3. ADDRESS OF OPERATOR  
P.O. Box 4289, Farmington, NM, 47499-4289

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1585' FSL, 945' FEL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input checked="" type="checkbox"/>	<input type="checkbox"/>
(other) <input type="checkbox"/>	<input type="checkbox"/>

5. LEASE  
SF 080117

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME  
Huerfanito Unit

8. FARM OR LEASE NAME  
Huerfanito Unit

9. WELL NO.  
#40

10. FIELD OR WILDCAT NAME  
Ballard Pictured Cliffs

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 27, T-27-N, R-9-W

12. COUNTY OR PARISH  
San Juan

13. STATE  
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
6339' DF

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1) Pull the 1" tubing and run in a 1½ work string.
- 2) Circulate the hole with mud and spot a 50 sk plug to fill from TD to 1870' to cover the Fruitland and Pictured Cliffs. (50 sk)
- 3) Perforate the 5½" casing at 1555' and squeeze cement from 1555' to 1285' behind the casing. (45 sk) Spot a plug from 1555' to 1285' inside the casing. (35 sk) To cover the Kirtland and Ojo Alamo formations.
- 4) Perforate the 5½" casing at 147' and cement inside and outside the 5½" casing to surface. (44 sk)
- 5) Install a dry hole marker.
- 6) Remove the surface equipment and restore surface.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_

18. I hereby certify that the foregoing is true and correct

SIGNED William R. Wicks TITLE Production Engineer DATE December 7, 1982

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

**APPROVED**

DEC 09 1982

FOR JAMES F. SIMS

DISTRICT ENGINEER

\*See Instructions on Reverse Side