

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF 080382A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

(Communitized)

8. FARM OR LEASE NAME

Frontier-Aztec Unit B

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR NEK. AND

SURFACE OR AREA

1/4 Sec. 27N, R 11W,

NE 1/4

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

The Frontier Refining Company

3. ADDRESS OF OPERATOR

4040 E.Louisiana Avenue, Denver, Colorado 80222

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

1850' fr. S line and 790' fr W line of Sec.28 T 27N, R 11W,
NMP11 San Juan County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6299KB 6287 GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF

TEST WATER SHUT-OFF

☐
☐
☐
☐
☒

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACTURE TREATMENT

REPAIRING WELL

☐
☐
☐
☐
☐

SHOOTING OR ACIDIZING

ALTERING CASING

(Other)

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)


17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Mud flow from tubing.

Repair casing leak as follows:

Move in well service unit, kill well, if necessary; install B.O.P. and pull tubing. Run gauge ring and junk basket to PBD. Run wire line casing inspection log to locate possible leaks. Set bridge plug 50 feet above casing perforations in the Dakota.

Run packer on tubing to bridge plug; set packer and test plug. Pull tubing in increments and set and reset packer to test casing below packer. Isolate leaks and cement squeeze same. Drill out cement, pressure test casing; recement if necessary; drill bridge plug. Run tubing, swab or jet water out, if necessary, and place well on production.



18. I hereby certify that the foregoing is true and correct

SIGNED

E. B. Draville

TITLE Mgr.: Drilling & Production DATE Jan. 10, 1967

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side