

May 1983)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

(Other instructions on reverse side)

Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

NM-03603-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hammond

9. WELL NO.

41

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

25 - T27N, R8W

12. COUNTY OR PARISH

San Juan

13. STATE

N.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6,000 GR

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Production casing failure - December 17, 1975
Well to plugged and abandoned at request of U. S. Geological Survey;
in accordance with their letter of April 25, 1977 (copy attached):

1. Squeeze Mesa Verde perforations 3892' to 4568', below packer.
2. Cement Plug 2400 to 2250 feet to cover Pictured Cliffs formation.
3. Test casing to establish location of casing failure.
4. Squeeze hole(s) if holes are above 1400 feet. The 7" shall be perforated at 1400 feet and squeezed with at least 50 sacks cement and a 100 foot plug left 1400-1300 feet.
5. Squeeze bradenhead if cement doesn't circulate in step 4. Place 10 sack surface plug in surface of 7" casing with dry hole marker.

No casing to be pulled.

RECEIVED

MAY 2 1977

U. S. GEOLOGICAL SURVEY

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Operator

DATE 4-28-77

(This space for Federal or State office use)

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

MAY 2 1977

2. I. McGRATH

*See Instructions on Reverse Side

Approved Subject To