

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Federal Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Gordon A
3. Address of Operator Box 990, Farmington, N w Mexico - 87401	9. Well No. 1 (P & A)
4. Location of Well UNIT LETTER <u>0</u> , <u>990</u> FEET FROM THE <u>South</u> LINE AND <u>1650</u> FEET FROM THE <u>East</u> LINE, SECTION <u>24</u> TOWNSHIP <u>27N</u> RANGE <u>10W</u> NMPM.	10. Field and Pool, or Wildcat Fulcher Kutz P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 6525' GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.


Because of non-production it is planned to plug and abandon this well as follows:

Kill well and spot a 50 sack cement plug on bottom (est. top of cement plug is 2000'). Pull tubing.

Determine free point of 5 1/2" casing and shoot off above free point. Spot a 30 sack cement plug on casing stub by displacing cement down the freed casing (est. a 105' fill). Pull casing.

Place a 25 sack cement plug at base of surface casing. Place a 15 sack cement plug at surface with a 4' x 4" P & A marker.

Clean and level location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed F. H. WOOD TITLE Petroleum Engineer DATE 4-10-69

APPROVED BY [Signature] TITLE Sup Dist III DATE 4-11-69

CONDITIONS OF APPROVAL, IF ANY: