

5-000
1-F

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

5. Indicate Type of Lease
~~XXXXX~~ **Federal** ~~XXXXX~~

5. ~~XXXXX~~ Oil & Gas Lease No.
SF-078089

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name	
2. Name of Operator Beta Development Co.		8. Farm or Lease Name Hancock Federal	
3. Address of Operator 125 Petr. Club Plaza, Farmington, New Mexico		9. Well No. 1	
4. Location of Well UNIT LETTER K 1850 FEET FROM THE South LINE AND 1850 FEET FROM THE West LINE, SECTION 22 TOWNSHIP 27N RANGE 11W NMPM.		10. Field and Pool, or Wildcat Basin Dakota	
15. Elevation (Show whether DF, RT, GR, etc.) 6364' G.L.		11. County San Juan	


Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair casing leaks w/packer and Kem-Pac chemicals, as follows:

Rig up work over rig, circulate out mud, sand and shale to T.D. Circulate until hole is clean, BCH. Run Baker Model "D" production packer on wire line. Set Packer just below Greenhorn section w/bump out plug to keep any water or Kem-Pac material from getting below packer. GIH w/tbg, Model "D" locator and tail pipe. Spot Kem-Pac above Model "D", set tail pipe down on bump out plug, run tail pipe through Model "D" and land locator seals in packer. Flange up well head, swab well in, re-acidize if necessary.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. E. Bayler TITLE Superintendent DATE 4-1-68

APPROVED BY Emory Chandel TITLE Sup. Dist. 11 DATE 4-2-68
CONDITIONS OF APPROVAL, IF ANY: