

3-00C  
1-F

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease <del>XXXXXX</del> <input checked="" type="checkbox"/> <b>Federal</b> <del>XXXXXX</del>
5. State Oil & Gas Lease No. <b>SF-078094</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator <b>Beta Development Co.</b>	8. Farm or Lease Name <b>Hancock Federal</b>
3. Address of Operator <b>234 Petroleum Club Plaza, Farmington, New Mexico</b>	9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>M</b> , <b>1140</b> FEET FROM THE <b>South</b> LINE AND <b>790</b> FEET FROM THE <b>West</b> LINE, SECTION <b>14</b> TOWNSHIP <b>27 N</b> RANGE <b>11 W</b> NMPM.	10. Field and Pool, or Wildcat <b>Basin Dakota</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>6248' GR</b>	12. County <b>San Juan</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Repair casing leaks w/packer and Kem-Pac chemicals, as follows:**

Rig up workover rig, circulate out mud, sand and shale to T.D. Circulate until hole is clean. POH. Run Baker Model "D" production packer on wire line. Set packer just below Greenhorn section w/bump out plug to keep any water or Kem-Pac material from getting below packer. GIH w/tbg., Model "D" locator and tail pipe. Spot Kem-Pac above Model "D", set tail pipe down on bump out plug, run tail pipe through Model "D" and land locator seals in packer. Flange up well head, swab well in and re-acidize if necessary.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:  
SIGNED JOHN T. HAMPTON TITLE Manager DATE December 21, 1966

APPROVED BY [Signature] TITLE Sup. Dist. III DATE 12-23-66  
CONDITIONS OF APPROVAL, IF ANY: