

Lodewick #1

Orig. Comp. 4/51

TD = 2494' PBTD = 2490'

Page 2 of 2

1. Check location for anchors. Install if necessary. Test anchors.
2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOP.
3. POOH with 1 1/4" tbg. RIH with tbg and cement retainer. Set retainer at 2200'. Test casing integrity to 500#. Squeeze perfs at 2247' to 2370' with 40 cuft of cement. Pull out of retainer and spot 50' cement plug on top. RIH with pipe cutter and cut 3 1/2" csg at TOC. Pull pipe. Run short string CBL.
4. Depending where TOC is (est. 2244) besure that following have 100' cement inside and outside csg:

Fruitland Coal 2047'
Ojo Alamo 1373'
and 155' to surface

5. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
6. Contact FMC and ship surface equipment to yard or other location per instructions.
7. Turn over to John Schwartz for reclamation.
8. Rehabilitate location according to BLM or State requirements.