

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved
Budget Form No. 42-10124

5. LEASE DESIGNATION AND SERIAL NO.

SF 077974

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐

2. NAME OF OPERATOR
Tenneco Oil Company

3. ADDRESS OF OPERATOR
1850 Lincoln St. Suite 1200, Denver, Colorado 80295

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
M 895' FSL and 895' FWL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Lodewick

9. WELL NO.

#2

10. FIELD AND POOL, OR WILDCAT

Fulcher-Kutz PC

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 18, T27N, R9W

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DP, RT, GR, etc.)

6608' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input checked="" type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input checked="" type="checkbox"/>	ABANDON*	<input type="checkbox"/>
REPAIR WELL	<input checked="" type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		<input type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		<input type="checkbox"/>

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to do a workover on this well as follows:

1. Rig up and pull 1" syphon string. Use SLM to check TD rather than 1" tubing.
2. Run 3½" O.D. regular tubing W/notched collar and baffle in notched collar. Use foam to clean out cavings if necessary to set tubing through a minimum of 90% of the open hole. Reverse circulate with foam.
3. Pump 20 bbls. water to insure baffle is open. Cement 3½" tubing with 75 sxs. 65 cmt-35 poz, containing 12% gel and 12½ #/SX Kolite/Gilsonite, followed by 25 sxs. reg. cement containing 4% gel, 2% CaCl and 12½ #/SX Kolite/Gilsonite. Attempt to circulate cement to surface. WOC 12 hrs. to perforate. Do not use centralizers. Bump plug on baffle and hold pressure 6 hours. Do not over-displace.
4. Run GR-Neutron correlation log. Run 1½" tubing and spot 100 gals. DI 15% HCL. Pull tubing. Perforate 1 hole/ft. in cleanest sand sections. Minimum of 20 holes.
5. Frac down 3½" casing using 25,000 gals. 70% quality foam and 30,000# 10/20 sand @20 BPM. After wellhead pressure has fallen 250 PSI below shut in, slowly open well and recover water and broken nitrogen. Treatment water should be 1% KCL
6. Run 1½" tubing to approximately 20' of PBTD. Return well to production.
7. Clear location of debris.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Div. Production Manager

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 7 1977

*See Instructions on Reverse Side

U. S. GEOLOGICAL SURVEY

Okal