101.320.	State of New Me	xico	Form C 101
Submit 3 Copies to Appropriate District Office	Energy, Minerals and Natural Re		Form C-103 Revised 1-1-89
DISTRICT I P.O. Box 1980, Hobbs, NM 88240	OIL CONSERVATION P.O.Box 208		WELL API NO.
DISTRICT II P.O. Drawer DD, Artesia, NM 88210 Santa Fe, New Mexico 87504-2088			300450664000 5. Indicate Type of Lease
DISTRICT III	7410		STATE FEE X
1000 Rio Brazos Rd., Aztec, NM 8			6. State Oil & Gas Lease No.
(DO NOT USE THIS FORM FOR DIFFERENT RE	IOTICES AND REPORTS ON V PROPOSALS TO DRILL OR TO DEEP SERVOIR. USE "APPLICATION FOR	EN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name
1. Type of Well:	M C-101) FOR SUCH PROPOSALS.)		Bruce Sullivan
OIL GAS WELL 2. Name of Operator	X OTHER Attention:		8. Well No.
Arnoco Production Company 3. Address of Operator	Gail M. Je	ffersoj, Rm 1942	1
P.O. Box 800 Denver	Colorado 80201	(303) 830-6157	9. Pool name or Wildcat So. Blanco Pic. Cliffs
4. Well Location Unit Letter :	1650 Feet From The South	Line and 99	GO Feet From The East Line
Section 9	Township 27N	Range 9W N	IMPM San Juan County
	10. Elevation (Show whet	her DF, RKB, RT, GR, etc.)	
	Appropriate Box to Indicate INTENTION TO:	1	-
ERFORM REMEDIAL WORK	PLUG AND ABANDON		BSEQUENT REPORT OF:
EMPORARILY ABANDON		REMEDIAL WORK	ALTERING CASING
ULL OR ALTER CASING	J CHANGE PLANS []	CASING TEST AND CEN	
OTHER:		OTHER:	
work) SEE RULE 1103. Amoco Production Company	y requests permission to plug and	abandon the above refer	renced well per the attached procedures. The myself for any administrative questions.
			RECENTION MAY - 5 1995
			OIL COM, DUV.
I hereby certify that the information a	above is true and complete to the best of n	•	taff Asst. DATE 05-04-1995
TYPE OR PRINT NAME	Gail M. Jefferson	IIILE	DATE
(This space for State Use) APPROVED BY	Robinson Vale TOC Behind 5/2 18	TITLE DEPUTY OIL & GAS I	INSPECTOR, DIST. #3 MAY - 5 1995
pens. 4 usolate Farm.	, Kint., Ose of surface pipe	Shoe at 104'	
	to witness		

Sullivan Bruce #1
Orig. Comp. 8/53
TD = 2:242', PBTD = 2:217'
Page 2 of 2

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOP.
- 3. POOH with 1 1/4" tbg and lay_down. RI wireline and cement retainer. Set retainer at 2130'. Test casing integrity to 500#. RU Haliburton and squeeze perfs at 2186' to 2196' with 14 cuft of cement from surface. Drop rubber plug and fill hole to surface with 107 cuft cement.
- 4. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
- 5. Turn over to John Schwartz for reclamation.
- 6. Rehabilitate location according to BLM or State requirements.

BRUCE SULLIVAN 001 713
Location — 91— 27N— 9W
SINGLE PC
Orig.Completion — 8/53
Last File Update — 1/89 by DDM

