

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Rowley
9. Well No. 7
10. Field and Pool, or Wildcat Fulcher-Kutz P. C.
12. County San Juan

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator El Paso Natural Gas Company
3. Address of Operator Box 990, Farmington, New Mexico - 87401
4. Location of Well UNIT LETTER K , 1850 FEET FROM THE South LINE AND 1825 FEET FROM THE West LINE, SECTION 7 TOWNSHIP 27N RANGE 10W NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 5811' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER Convert to a Water Well <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>


17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is planned to plug and abandon the Pictured Cliffs pay zone in this well and leave it as a producing water well by the following method.

Spot a 50 sack cement plug from total depth (1676') to approximately 1200'.

Pull tubing, remove xmas tree and install a 5 1/2" x K 1" swage and 1" valve.

Leave surface casing valve in place to control the flow of water from the surface casing.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Original Signed F. H. WOOD</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>3-31-69</u>
APPROVED BY <u><i>Emery Clavel</i></u>	TITLE <u><i>Asst. Dir. III</i></u>	DATE <u>4-2-69</u>
CONDITIONS OF APPROVAL IF ANY:		