Form 3160-5

UNITED STATES

FORM APPROVED Budget Bureau No. 1004-0135

Use "APPLICATION FOR SUBMIT	7. If Unit or CA, Agreement Designation		
1. Type of WeI Oil Well Well Other 2. Name of Operator Marathon Oil Company 3. Address and Telephone No.		8. Well Name and No. Alice Bolack No. 7 9. API Well No.	
P.O. Box 2409, Hobbs, NM 88240	(505) 393-7106	30-045-06739 10. Field and Pool, or exploratory Area	
4. Location of Well (Footage, Sec., T., R., M., or Survey Des Unit Letter A. Section 9, T-27-N, R 990° FNL & 990° FEL	1-11-₩	West Kutz Canyon PC 11. County or Parish, State San Juan, NM	
CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REF	ORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF AC	OTION	
Notice of Intent Subsequent Report Final Abandonment Notice	Abandonment Recompletion Plugging Back X Casing Repair Altering Casing X Other Request TA Status	Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water	
. Describe Proposed or Completed Operations (Clearly state all give subsurface locations and measured and true vertice)	pertinent details, and give pertinent dates, including estimated date ical depths for all markers and zones pertinent to this work.)*	(Note: Report results of multiple completion on Completion or Recompletion Report and Log fo	

	4 Pr) 15 - 4				
4. I hereby certify that the foregoing is true and correct Signed	Title Production Engineer		Date _2	Dato 2/24/98	
(This space for Federal or Sinte office use) Approved by Conditions of approval, if any:	Title	eldray to the	Date	MAP - 2 1902	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Alice Bolack Well No. 7 San Juan County, NM UL "A", Sec 9 T-27-N, R-11-W 990 FNL, 990 FEL

Subsequent Report

MIRU PU. ND wellhead and NU BOP equipment.

Pick up and TIH with 5 12/" casing scraper to top of CIBP. POOH.

TIH with packer. Set packer and test CIBP, tested OK. Tested annulus, leaked.

POOH testing. Found leak at approximately 15'. Finish POOH, laying down.

ND BOP equipment and NU wellhead. RDMO PU.

Procedure to Repair Casing Leak

- 1. MIRU PU. Remove intermediate wellhead.
- 2. Install pipe jacks and floor.
- 3. RIH with 5-1/2" casing spear. Pull slips. Set down with casing string.
- 4. RU wireline. Back off 5-1/2" casing at \pm 42' from surface with tension pulled on casing (string shot).
- 5. RD wireline. POOH with 1 joint of 5-1/2" casing.
- 6. RIH with 1 joint of 5-1/2" casing and screw onto casing string.
- 7. Pull up and set slips. Make cutoff.
- 8. Install intermediated wellhead.
- 9. RDMO PU.
- 10. Notify BLM of casing integrity test. Perform casing integrity test.