

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. NM-012202
2. NAME OF OPERATOR Tenneco Oil Company E & P WRMD	6. IF INDIAN ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 3249, Englewood, CO 80155	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below) At surface 1550' FNL, 1650' FEL	8. FARM OR LEASE NAME Bolack B LS
9. WELL NO. 1	10. FIELD AND POOL, OR WILDCAT Blanco Mesaverde
11. SEC., T., R., M., OR BLK. AND SURVEY OF AREA Sec. 33, T28N, R8W	12. COUNTY OR PARISH 13. STATE San Juan NM
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, CA, etc.) 5800' GL

BUREAU OF LAND MANAGEMENT
FARMINGTON RESOURCE AREA

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input checked="" type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input checked="" type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input checked="" type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input checked="" type="checkbox"/>	CHANGE PLANE <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Tenneco requests permission to plug off, sidetrack, run casing, and recompleat the referenced well according to the attached detailed procedure.

RECEIVED
SEP 12 1985
OIL CON. DIV.
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED

Scott McKinn

TITLE Sr. Regulatory Analyst

DATE May 15, 1985

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

SEP 10 1985

DATE

AREA MANAGER
FARMINGTON RESOURCE AREA


*See Instructions on Reverse Side

NMOCC

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

MV & PC OPEN HOLE

SIDETRACK WORKOVER PROCEDURES-A



4111-1

LEASE Bolack B

WELL NO. 1

9-5/8" OD, 25.4 LB, CSG.W/ 150 SX

TOC @ surface

7" OD, 20 LB, CSG.W/ 300 SX

TOC @ 1910'

DETAILED SIDETRACKING PROCEDURE:

1. Prepare location by blading and installing anchors, if necessary. Install blowdown lines and blow well.
2. MIRUSU. Kill tbg w/1% KCl water.
3. NDWH. NU 11" 3M csg spool w/2-1/16" 3M plug valve. NU 7-1/16" DSA. NU 6" 3000 psi BOPE. NU blowdown lines to BOP.
4. Kill annulus w/1% KCl water.
5. POOH laying down 2-3/8", 4.7# tubing. Visually inspect tbg on trip out.


NOTE: If tbg is stuck, do not pull over 40K# as tbg may be in very poor condition. RIH w/jet cutter and attempt first shot at least 100' below the 7" csg shoe.

6. RUWL and run GR-CCL log from 100' below 7" csg shoe to the Fruitland Coal top. RIH on wireline and set Baker cement retainer approx 200' above the 7" csg shoe. PU stinger, crossover, 2-7/8" drill pipe and TIH. Fill hole and PT to 1500 psi prior to stinging into retainer.
7. Sting into retainer and establish injection rate. Squeeze open hole w/300 sxs Class H w/1% CaCl₂ (15.6 ppg, 1.18 FT³/SK, 5.2 GAL/SK; sidetrack plug). Sting out, pick up 30', and reverse tbg clean. TOOH and LD stinger.

NOTE: Have cement tested w/field water for pump time and 24 hour compressive strength prior to cementing.

8. RDMOSU.
9. MIRU Dwinell Bros. Rig #1. RU to drill w/water.
10. TIH w/6-1/4" J-1 bit, bit sub, 10 4-3/4" drill collars, and balance of drill pipe to TOC. Drill out cement retainer, and dress off open hole plug to 15' below the 7" csg shoe. Circulate hole clean and TOOH.
NOTE: Caliper ALL tools, O.D. and I.D., before running in hole.
11. RU to drill w/gas. PU 6-1/4" J-33 bit, knuckle joint kick-off assembly, 4-3/4" drill collars and TIH. Blow hole dry w/N₂. Take inclination (TOTCO) survey on wireline before drilling. Drill 15'-20' and take another TOTCO survey. When angle has built approx 7°, blow hole clean and POOH.
12. LD knuckle joint. TIH w/J-33 bit, 6-3/16" near bit reamer, and 4-3/4" drill collars. Drill Mesaverde section w/gas to approx 450' below the top of the Point Lookout. Take TOTCO surveys every 500' or less as required, recording all surveys in the daily log. At T.D., blow hole clean and TOOH for logs.

MESAVERDE SIDETRACK WORKOVER - B



4111-2

LEASE Bolack B WELL NO. 1
9-5/8 "OD, 25.4 LB, CSG.W/ 150 SX
 TOC @ Surface
7 "OD, 20 LB, CSG.W/ 300 SX
 TOC @ 1910'

DETAILED SIDETRACKING PROCEDURE (CONTINUED):


13. RUWL and run GR-DIL and GR-CDL-Caliper over entire open hole. TIH for wiper trip, blow hole clean, POOH laying down, and RU to run csg.
14. Run 4-1/2" 10.5# K-55 STC csg as a full string as follows:
 - A) Conventional float shoe and shut off baffle one joint up.
 - B) One centralizer w/stop ring in the middle of the shoe joint and one centralizer on the collar above. Run one centralizer on every other collar in the open hole. Place one centralizer on the first collar below the wellhead (approx 15 centralizers total).
 - C) Run at least 1 short (flag) joint approx 200' off bottom.
 - D) Run stage collar tool @ 3500 ft. (approx 200' above 7" shoe).
 - E) Casing will be electronically inspected before arriving on location. Visually inspect body and end areas and drift to 4.052".
 - F) Thread lock all connections up to and including the float collar. Use API csg dope on all remaining connections. Recommended csg torque is 1460 ft-lbs.
15.
 - A) Precede 1st stage cement w/10 BBLS mud flush containing fluid loss additive.
 - B) Reciprocate csg w/20' strokes and cement first stage w/150* sx Class B containing 6/10% fluid loss additive (D-60, Halad-9).
 - C) Drop shut-off plug and displace w/72 BBLS 1% KCl water. If plug does not bump, do not overdisplace.
 - D) Drop opening bomb. After allowing time for bomb to seat, pressure up csg to open stage tool.
 - E) Cement 2nd stage w/300 sx 65/35 POZ-mix containing 6% gel (12.4 ppg, 1.84 FT.³/SK, 9.9 gal/SK) & tail-in w/50 sx Class B containing 2% KCl.
 - F) Drop closing bomb and displace w/56 BBLS fresh water. If plug does not bump, do not overdisplace.
 *Final amount to be determined by caliper log + 10%.

NOTE: Have cement blends tested w/field water for pump time and 24 hour compressive strength prior to pumping. Use cementing company's csg hardware (float shoes, float collars, stage collars, etc.).
16. Set slips w/full csg weight. NDBOP and cut off 4-1/2" csg. NU tbg spool. PT wellhead to 3000 psi.
17. RDMO Dwinell Bros. #1.

[Signature]
 Drilling Department

MESAVERDE SIDETRACK

COMPLETION DIAGRAM - C



4111-3

LEASE Bolack B WELL NO. 1
 9-5/8" OD, 25.4 LB, CSG.W/ 150 SX
 TOC @ Surface
 7" OD, 20 LB, CSG.W/ 300 SX
 TOC @ 1910'

DETAILED COMPLETION PROCEDURE:

18. MIRUSU. NU BOPE.
19. PU 3-7/8" bit, csg scraper, 2-3/8" 4.7# J-55 EUE 8rd tbg & tally in hole. Fill hole & PT csg to 3500 psi. Rev hole clean & displace w/1% KCl wtr.
20. Spot a sufficient quantity of 7-1/2% DI HCl to cover the perforated interval + 200'. POOH & LD bit & scraper.
21. RUWL. Run GR-CCL fr PBTD to 150' above the highest pay. Perf the Lower Mesaverde under lubricator as directed by the Geological Dept from the top interval down. Use 3-1/8" hollow carrier csg guns loaded 2 JSPF @ 120° phasing.
22. Acidize down csg w/20 gal per perf of 15% wgt'd HCl containing 600# NaCl/1000 gal & 1.5 1.1 SG RCN ball sealers per perforation. Displace at maximum rate w/MSP less than 3500 psi.
23. RIH w/junk basket on WL to knock off & recover ball slrs.
24. RU & frac Lower Mesaverde w/slickwater containing 1% KCl, 15#/1000 gal friction reducer & 2500#/ft 20/40 sand @ 1 BPM/perf; fluid/sand design on following page. Flush to 10 BBLS shy of top perf & close blind rams ASAP.
25. RUWL & RIH w/Baker 4-1/2" RBP. Set approx 50' above top perf. Dump 2 sx frac sand on RBP, load csg w/1% KCl water, & PT RBP to 3500 psi.
26. TIH w/2-3/8" tbg to approx 10' above the RBP & spot a sufficient quantity of 7-1/2% DI HCl to cover the top perf + 200'. POOH.
27. RUWL. Perforate the Upper Mesaverde under lubricator as directed by the Geological Engineering Dept from the top interval down. Use 3-1/8" hollow carrier csg gun loaded w/2 JSPF @ 120° phasing.
28. Acidize down csg w/20 gal per perf of 15% wgt'd HCl containing 600# NaCl/1000 gal & 1.5 1.1 SG RCN ball sealers per perforation. Displace at max rate w/MSP less than 3500 psi.
29. RIH w/junk basket on wireline to knock off & recover ball sealers.
30. RU & frac Upper Mesaverde w/slickwater containing 1% KCl, 15#/1000 friction reducer, & 2500#/ft 20/40 sand @ 1 BPM/perf; fluid/sand design on following page. Flush to 10 BBLS shy of top perf.
31. RD frac head. PU retrieving head for 4-1/2" RBP & TIH on 2-3/8" tubing. CO to RBP w/foam. Latch on to RBP & POOH. LD RBP & retrieving head.

MESAVERDE SIDETRACK

COMPLETION DIAGRAM - C

4111-4

LEASE Bolack B WELL NO. 1
 9-5/8" OD, 25.4 LB, CSG.W/ 150 SX
 TOC @ Surface
 7" OD, 20 LB, CSG.W/ 300 SX
 TOC @ 1910'

DETAILED COMPLETION PROCEDURE (CONTINUED):

32. TIH w/2-3/8" production string as follows:
 1 jt 2-3/8" tbg
 1 1.781" ID SN w/expendable plug
 Balance of 2-3/8" tbg
33. Tag fill & record amount. CO to PBTD w/N₂ foam. PU & set bottom of tbg within 20' of lowest perforation. Land tbg & NUWH.
34. Kick well around w/N₂ & FTCU.
35. RDMOSU. SWI for AOF.

MESAVERDE FRAC DESIGN:

1. 2500 #20/40 sand per ft. net pay.
2. 2 BPM per ft. net pay.
3. Fluid to contain 1% KCl, 15#/1000 gal friction reducer.
4. Schedule
 30% pad
 1 csg volume @ 1/2 ppg 20/40 sand
 1 csg volume @ 1 ppg 20/40 sand
 1 csg volume @ 1-1/2 ppg 20/40 sand
 Remains @ 2 ppg 20/40 sd

Peter M. Mueller
 Production Department

