Form approved. Budget Bureau No. 1004-0135 Form 3160-5 UNITED STATES SUBMIT IN TRIPLICATE. Expires August 31, 1985 DEPARTMENT OF THE INTERIOR (Other Instructions on re-(November 1983) 5. LEASE DESIGNATION AND SERIAL NO. (Formerly 9-331) BUREAU OF LAND MANAGEMENT SF 078566 A 6. IF INDIAN, ALLOTTEE OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT" for such proposals.) 1. 7. UNIT AGREEMENT NAME WELL GAS Well XX OTHER S. PARM OR LEASE NAME NAME OF OPERATOR Howell El Paso Natural Gas Company 3. ADDRESS OF OPERATOR 9. WELL NO. Farmington, New Mexico P.O. Box 4289, LOCATION OF WELL (Report location clearly and in accordance with any state requirement.) E D At surface 10. FIELD AND POOL, CR WILDCAT Blanco Mesa Verde UG 01 1985 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA BUREAU OF LAND MANAGENIEN 1550 FSL - 1090 FWL EVEWINGTON DESOURCE AREA Sec 27, T28N, R8W, NMPM 14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 12. COUNTY OR PARISH | 13. STATE 6262 GL San Juan 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSCOUDING REPORT OF TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL MULTIPLE COMPLETE FRACTURE TREATMENT PRACTURE TREAT ALTERING CARING ARANDON SHOOTING OR ACIDIZING SHOOT OR ACIDIZE ABANDONMENT<sup>®</sup> CHANGE PLANS REPAIR WELL (Other) (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other)Sidetrack, Case, Cement, & Frac xx 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) • In order to increase production it is planned to workover and restimulate this well in the following manner: Pull tubing, set a drillable bridge plug near the bottom of the 7" casing & pressure test to If tubing is stuck, cut off tubing approximately 100° below the 7" casing shoe, set a drillable cement retainer near the bottom of the 7" casing, squeeze the open hole with approximately 200 sks. cement. Pressure test the 7" casing to 1000 psi. Isolate & squeeze cement any leaks. If leaks are squeezed near the base of the Ojo Alamo, no additional block squeeze of the 7" annulus is planned. If there are no leaks near the base of the Ojo Alamo, perforate two squeeze holes at the base of the Ojo Alamo and block squeeze the 7" annulus with approximately 125 sks cement. Clean out if hole conditions permit, otherwise, sidetrack and drill to approximately 5350 . Run a full string of 4 1/2" production casing and sufficient amount of cement to tie into the 7" casing shoe. Selectively perforate & sandwater frac the Mesa Verde formation. AUG 05 1985 18. I hereby certify that the foregoing is true and correct DIST. 3 7-31-85 SIGNED TITLE (This space for Federal or State office use) APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

FARMINGTON RECOURCE AREA