

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-588-2

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO SEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	N/A
Union Texas Petroleum Corporation	8. Firm or Lease Name
3. Address of Operator	State Com
375 US Highway 64, Farmington, NM 87401	9. Well No.
4. Location of Well	1
UNIT LETTER G 1917 FEET FROM THE North LINE AND 1776 FEET FROM	10. Field and Pool, or Wildcat
THE East LINE, SECTION 16 TOWNSHIP 28N RANGE 9W NMPM.	Basin Dakota
15. Elevation (Show whether DF, RT, CR, etc.)	12. County
6408 GL	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. MIRU.
2. Set cement retainer at 6045' KB. Pump 100 sxs C1 "B" cement below retainer. Sting out and dump 2 sxs C1 "B" on retainer.
3. Shoot 2 - 0.32" holes at 4330'. Squeeze with 25 sxs C1 "B" cement. Spot 10 sxs in casing at 4330'.
4. Shoot 2 - 0.32" holes at 3730'. Squeeze with 25 sxs C1 "B" cement. Spot 10 sxs in casing at 3730'.
5. Spot 10 sxs C1 "B" cement at 2750'.
6. Shoot 2 - 0.32" holes at 330'. Would not circulate. Trip in hole to 330'. Cement to surface with 25 sxs C1 "B". Squeeze 10 sxs C1 "B" down Bradenhead.
7. Shut in with 200 psi left on Bradenhead.
7. Install dry hole marker.
8. Site to be reclaimed in Fall of 1987.

RECEIVED
OCT 20 1986
OIL CON. DIV.
SANTA FE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Robert C. Frank TITLE Permit Coordinator DATE 10/24/86

Original Signed by EDNAK E. CHAVEL

APPROVED BY EDNAK E. CHAVEL TITLE Permit Coordinator DATE OCT 20 1986

CONDITIONS OF APPROVAL, IF ANY: