



AMOCO PRODUCTION COMPANY

WELL ANALYSIS COMPARISON

LEASE: RIDDLE FLS. NO. 2

MARCH 27, 1992


M-8-28-8

	BRADENHEAD	INTERMEDIATE	CASING
	-----	-----	-----
DATE:	3/26/92	3/26/92	3/26/92
NO.:	NO PRESSURE ON BRADENHEAD	20207	20208
	MOLE %	MOLE %	MOLE %
	-----	-----	-----
NITROGEN		0.750	0.258
CO2		0.199	0.512
METHANE		88.671	86.657
ETHANE		5.843	6.989
PROPANE		3.127	3.354
I-BUTANE		0.356	0.542
N-BUTANE		0.650	0.847
I-PENTANE		0.157	0.269
N-PENTANE		0.118	0.194
HEXANE+		0.129	0.378
BTU'S		1131.1	1169.9
	-----	-----	-----
GPM		2.8959	3.5636
	-----	-----	-----
GRAVITY		0.6423	0.6671
	-----	-----	-----

RECEIVED

APR 1 1992

OIL CO. DIV



UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED
BLM

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

SF-080112
SF-078499

6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

82 MAR 13 AM 11:57

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

BLM ALBUQUERQUE, N.M.

SUBMIT IN TRIPLICATE

7. If Unit or CA, Agreement Designation

1. Type of Well

Oil Well Gas Well Other

8. Well Name and No.

Riddle F LS #X

2. Name of Operator

Amoco Production Company Attn: John Hampton

9. API Well No. C7591

30-045-22746

3. Address and Telephone No.

P.O. Box 800 Denver, Colorado 80201

10. Field and Pool, or Exploratory Area

Blanco Mesaverde

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990 1670 FWL
1667' FSL, 1750' FEL Sec. 8, T28N-R8W Unit "J"

11. County or Parish, State

San Juan, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

- Notice of Intent
- Subsequent Report
- Final Abandonment Notice

- Abandonment
- Recompletion
- Plugging Back
- Casing Repair
- Altering Casing
- Other Bradenhead Repair

- Change of Plans
- New Construction
- Non-Routine Fracturing
- Water Shut-Off
- Conversion to Injection
- Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Amoco intends to perform the attached workover procedure required to eliminate bradenhead pressure.

In addition, Amoco also requests approval to construct a temporary 15'X15'X 5' blow pit for return fluids. This pit will be reclaimed if utilized, upon completion of this operation.

RECEIVED
APR 1 1992

APPROVED

MAR 19 1992

AREA MANAGER

OIL CON. DIV.

DIST. 3

Please contact Ed Hadlock (303) 830-4982 if you have any questions.

14. I hereby certify that the foregoing is true and correct

Signed J. L. Hampton /wll

Title Sr. Staff Admin. Supv.

Date 3/11/92

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any: _____

Title _____

Date _____

AMOOD

Workover Procedure
Riddle F LS #2
Sec.08-T28N-R08W
San Juan County, NM

1. Contact Federal or State agency prior to starting repair work.
 2. Catch gas and/or water sample off of bradenhead and casing, and have analyzed.
 3. Install and/or test anchors.
 4. MIRUSU. Check and record tubing, casing and bradenhead pressures.
 5. Blow well down, kill well if necessary with 2% KCL.
 6. Nipple down well head, nipple up and pressure test BOP's.
 7. Trip in the hole and tag PBTD, check for fill, trip and tally out of hole with tubing checking condition of tubing.
 8. Trip in the hole with bit and scraper to the top of the perforations. A seating nipple and standing valve may be run in order to pressure test the tubing.
 9. Trip in the hole with RBP and PKR. Set RBP 50-100 ft. above perforations. Trip out of hole one joint and set PKR and pressure test RBP to 1500 psi. Release PKR and pressure test csg to 1000 psi. If no leak is found, spot sand on RBP, trip out of hole and skip step 10.
 10. Trip out of hole isolating leak in casing. NOTE: Once leak is located contact Brent Miller in Denver at (303) 830-4049. Spot sand on RBP and trip out of hole with PKR.
 11. Determine from well file and history if a CBL needs to be run from the top of RBP to bottom of intermediate casing shoe. If this is needed, run CBL under 1000 psi and report results to Denver.
 12. Bleed off any intermediate casing pressure and check for flow, fill annulus with 2% KCL water. Nipple down BOP's and tubing head, spear casing and remove slips, nipple up BOP's.
 13. Run freepoint and back off casing as deep as possible but not below the intermediate casing shoe. Trip out of hole laying down and checking condition of casing.
-

14. Trip in the hole with bit and scraper to top of casing back off, circulate hole clean and trip out with scraper.
 15. Trip in the hole with RBP and PKR and set RBP above casing backoff, trip out of hole one joint and set PKR and pressure test RBP.
 16. Release packer and trip out of hole isolating leak in casing. NOTE: IF this can not be accomplished contact Brent Miller in Denver (303) 830-4049.
 17. Release PKR and spot sand on RBP and trip out of hole.
 18. Run, if necessary a CBL & CCL to determine cement top on the intermediate casing.
 19. Perforate casing, if necessary with 4 JSPF and circulate dye to determine cement volume. Depending on the depth of the hole and circulating pressure, a PKR or a cement retainer may be needed.
 20. Mix and pump sufficient cement (class B or equivalent with two hour setting time) to circulate to surface. Shut bradenhead valve and attempt to obtain a squeeze pressure and WOC.
 21. Trip in the hole with bit and scraper and drill out cement and pressure test casing. Re-squeeze leaks if casing fails pressure test.
 22. Trip in the hole with retrieving head for RBP, circulate sand off of RBP and trip out of hole with plug.
 23. Trip in the hole with casing and tag casing backoff. Circulate the top of the back off clean with 2% KCL water. Circulate PKR fluid to fill annulus if no additional squeeze work is required. This will be determined from the previous CBL run. Tie back onto production casing and pressure test casing.
 24. Nipple down BOP's and tubing head, set slips and make cut off. Install tubing head and BOP's and pressure test.
 25. Trip in the hole with retrieving head for RBP, circulate sand off of RBP with 2% KCL and trip out of hole with plug.
 26. Trip in hole with a sawtooth collar and/or bailer and clean out to PBTB and trip out of hole.
 27. Trip in the hole with the production string (1/2 mule shoe on bottom and a seating nipple one joint off bottom), land tubing to original depth. Nipple down BOP's, nipple up well head.
-

28. Swab well in and put well on production.
29. Rig down move off service unit.