

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT TO THE DIRECTOR
(Other instructions on reverse side)

Budget Bureau No. 42-R1424

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER 2. NAME OF OPERATOR Gulf Oil Corporation 3. ADDRESS OF OPERATOR Box 670, Hobbs, New Mexico 88240 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 14. PERMIT NO.		5. LEASE DESIGNATION AND SERIAL NO. 078094 6. IF INDIAN, ALLOTTEE OR TRIBE NAME 7. UNIT AGREEMENT NAME 8. FARM OR LEASE NAME Fullerton Federal 9. WELL NO. 8 10. FIELD AND POOL, OR WILDCAT Kutz Gallup 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 6ec 14, 27-N, 11-W 12. COUNTY OR PARISH San Juan 13. STATE New Mexico	
15. ELEVATIONS (Show whether OF, RT, OR, etc.) 6187' GL			

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

6670' TD, 6424' PB.

Load hole with mud laden fluid. Run seal assembly and set in Model D packer at 6424'. Squeeze Dakota perforations 6446, 6622' with 50 sacks of Class A cement. Dump excess cement on top of packer. Run cement retainer on tubing and set at 5774'. Squeeze Kutz Gallup perforations 5824 - 5838' with 35 sacks of Class A cement. Dump excess cement on top of retainer. Cut and recover 5-1/2" casing from 1500'. Spot 55 sack, 200', of Class A cement in and out of 5-1/2" stub. Spot 45 sack, 100', Class A cement plug from 1050' to 950', across Ojo Alamo sandstone. Spot 30 sack, 100', Class A cement plug across 8-5/8" shoe at 234'. Spot 30 sack Class A cement plug from 100' to surface. Install dry hole marker and clean location.

RECEIVED

MAR 20 1972

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.


FILED

MAR 21 1972

CON. COM.
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED



TITLE Area Engineer

DATE March 17, 1972

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: