

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease <b>xxxxxx Federal xxxxxx</b>
5. State Oil & Gas Lease No. <b>SF-078896</b>

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>Beta Development Co.</b>	7. Unit Agreement Name
3. Address of Operator <b>234 Petroleum Club Plaza, Farmington, New Mexico</b>	8. Farm or Lease Name <b>Mudge Federal</b>
4. Location of Well UNIT LETTER <b>B</b> , <b>840</b> FEET FROM THE <b>North</b> LINE AND <b>1535</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>27 N</b> RANGE <b>11 W</b> NMPM.	9. Well No. <b>6</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>6180' GR</b>	10. Field and Pool, or Wildcat <b>Basin Dakota</b>
12. County <b>San Juan</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JQB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rig up work over unit, circulate all mud and shale out of well w/fresh water 1% Calcium Chloride, CO to T.D. Pull 1-1/2" tbg. out of well, GIH w/3-7/8" bit on 2-7/8" tbg., ream out any tight places in csg. CO to T.D. Circulate hole clean. POH and run packer on 2-7/8" tbg. w/two-seal assembly w/perforated nipple in between seals, bull plug on bottom w/stop ring. Set packer, pull tbg. up until stop ring catches at bottom of packer. This will have bottom seal assembly in side of Model "P" Packer. Pump in cement, displace w/water overflush w/2 bbls., slack tbg. off until top assembly sets down on packer. Swab well in. Release rig. After well has cleaned up, re-acidize w/500 gals. 15% regular mud acid.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:  
**JOHN T. HAMPTON**

SIGNED \_\_\_\_\_ TITLE **Manager** DATE **December 21, 1966**

APPROVED BY *Emery C. Carter* TITLE *Sup Dist 116* DATE *12-23-66*

CONDITIONS OF APPROVAL, IF ANY:



11/20/66  
HAMPSON

