

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)


1. oil ☐ well    gas ☒ well    other ☐  
2. NAME OF OPERATOR  
Southland Royalty Company  
3. ADDRESS OF OPERATOR  
P. O. Drawer 570, Farmington, NM 87499  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1520' FNL & 1725' FWL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
CHANGE ZONES ☐  
ABANDON\* ☐  
(other) ☐

SUBSEQUENT REPORT OF



(NOTE: Report results of multiple completion or zone change on Form 9-330.)

5. LEASE  
SF-077874  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Hanks  
9. WELL NO.  
#16E  
10. FIELD OR WILDCAT NAME  
Basin Dakota  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Section 6, T27N, R9W  
12. COUNTY OR PARISH  
San Juan  
13. STATE  
NM  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
6350' GL

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1-10-83 Rig up and pull 2-3/8" tubing. Trip in with 5-1/2" packer and test shoe to 2500 psi. POOH. TIH, set BP @ 6966' & pkr @ 6935'. Swab from perfs @ 6955' & 6961', 13 bbls gas cut water in 11 hrs.  
1-11-83 Move BP to 6935' & pkr to 6840' to test perfs @ 6858' & 6876'. Swab 27 bbls water in 11 hrs.  
1-12-83 Trip to dress BP & work on tongs.  
1-13-83 TIH & set BP @ 6837' & pkr @ 6740' to test perfs 6802', 6807', 6813'. Swab 8 BO & 7 BW in 11 hours. Test backside to 2000 psi. POOH.  
1-14-83 TIH with drillable BP & set @ 6836'. Run 223 joints 2-3/8" tubing & land at 6796'. Swab to kick off and rig down.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Engineer DATE January 26, 1983

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED FOR RECORD

FEB 1 1983

\*See Instructions on Reverse Side

NMOCO

[illegible]