

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-046563

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Feasel

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Fulcher Kutz P. C.

11. SEC., T., R., M., OR BLE. AND
SURVEY OR AREA

Sec. 33-T28N-R10W

N.M.P.M.

12. COUNTY OR PARISH

San Juan

13. STATE

New Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Petroleum Corporation of Texas

3. ADDRESS OF OPERATOR

P. O. Box 911, Breckenridge, Texas 76024

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1660' FSL and 950' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Plug and Abandon

☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*It is proposed to Plug and Abandon this well in the following
manner:1. A 60 sx cement plug has been set from 2040' to 1750'.
(5½" casing is at 2027')2. A. If cut and pull 5½" casing more than 100' below base
of Ojo Alamo:

1. Set 100' cement plug in and out of casing stub.

2. Set 100' cement plug at base of Ojo Alamo.

3. If have water flow, set 100' cement plug at 300'.

B. If cut and pull 5½" casing above Ojo Alamo.

1. Perforate casing at base of Ojo Alamo.

2. Squeeze perforations with sufficient cement to have
100' of cement in annulus and inside casing.

3. If have water flow set 100' cement plug at 300'.

3. Set 50' cement plug at base of surface casing.

4. Set cement plug in top of surface casing with dry hole
marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Ewell N. Walsh, P. E.

TITLE

President, Walsh Engineering
& Production Corp.

DATE

Oct. 21, 1974

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

*See Instructions on Reverse Side

