





R & G DRILLING COMPANY  
SCHLOSSER NO. 15

PLUGGING PROCEDURE

9-5/8", 28 lb., set at 90 feet with 100 sacks.  
5-1/2", 14 lb, set at 1653 feet with 200 sacks.  
Calculated top of cement in 8-3/4" hole - 718 feet.

Formation Tops:

Pictured Cliffs	- 1575'
Fruitland	- 1365'
Ojo Alamo	- 440'

Perforations: 1582' - 1602'

Well will be plugged in the following manner:

1. No casing will be pulled.
2. Spot cement plug 1602' to 1502' - 11 sacks.
3. Spot cement plug 1415' to 1315' - 11 sacks.
4. Perforate at 490'.
5. Spot cement plug at 490' - 32 sacks.  
Squeeze 21 sacks through perforations to spot 100' outside  
5-1/2" casing. Leave 100' plug inside 5-1/2" casing.
6. Spot surface plug at 140' - 16 sacks.
7. Set surface marker.
8. Clean up location and rehabilitate to BLM stipulations.