

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Merrion Oil & Gas Corporation		8. FARM OR LEASE NAME Phillips	
3. ADDRESS OF OPERATOR P. O. Box 840, Farmington, NM 87499		9. WELL NO. #1	
4. LOCATION OF WELL (Report location clearly and in accordance with State requirements. See also space 17 below.) At surface 990' FSL & 1650' FWL		10. FIELD AND POOL, OR WILDCAT West Kutz Pic. Cliffs	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 11, T28N, R13W	
15. ELEVATIONS (Show whether DF, or)		12. COUNTY OR PARISH 13. STATE San Juan New Mexico	

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETION	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input checked="" type="checkbox"/>
(Other)	<input type="checkbox"/>	(Other)	<input type="checkbox"/>

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work).\*

The workover proposed on the Sundry dated 7/31/85 was NOT performed. Instead, the attached P&A procedure is proposed for your approval.

RECEIVED  
SEP 12 1985  
OIL CON. DIV.  
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED L. Greg Merrion TITLE Production Engineer DATE September 4, 1985

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_

SEP 10 1985

**\*See Instructions on Reverse Side**

**NMOCC**

Exhibits No. 1

## 5.6. A PROCEDURE

LOCATION: 990' FSL and 1650' FWL  
Sec. 11, T28N, R13W  
San Juan Co., New Mexico

DATE: August 14, 1985

ELEVATION: 5910' KB

PREPARED BY: T. Gregory Merrion

PROCEDURE:

1. Move in, rig up Trend, Inc. Nipple down wellhead.
2. Pull out of hole and lay down 1" tubing. Pick up and run in hole with 2-3/8" tubing to 1727' and circulate hole full of water. Spot 100' cement plug across 5-1/2" casing shoe by pumping 125 sx cement and displacing with 5 Bbls water. Pick up tubing to 1500' and circulate hole full of mud.
3. Cut off casinghead and stretch casing to determine freepoint. Shoot 5-1/2" casing off at freepoint. Pull out of hole with casing and lay down. 100' plug across 5 1/2" casing shoe
4. Run in hole with 2-3/8" tubing to 575'. Establish circulation with mud. Spot 100' plug across bottom of 10-3/4" casing by pumping 50 sx cement and displacing with 1.5 Bbls mud. Pick up tubing to 235' and spot 100' plug across top of 10-3/4" casing by pumping 65 sx cement and displacing with 0.5 Bbls mud. Pick up tubing to 50' and circulate 50 sx cement to surface.
5. Install 4" dry hole marker at least 4' above GL. Weld the following on the marker:  

Phillips No. 1  
N Sec. 11, T28N, R13W
6. Rig down, move off Trend.
7. Clean and rehabilitate location as per BLM instructions.

Phillips No. 1  
N Sec. 11, T28N, R13W

APPROVED BY:

J. Gregory Merrion

DATE \_\_\_\_\_

8.22.8 ✓