Form 3160-5 (August 1999)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS on out use this form for proposals to drill or to re-enter an

FORM APPROVED
OMB NO. 1004-0135
Expires: November 30, 2000

5.	Lease Serial No.
	1 149 IND 8475

Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					ce or Tribe Name	
abandoned well. Ose form 5100-5 (APD) for Such proposals.					LOTTEE	
SUBMIT IN TRI	PLICATE - Other instruc	tions on reverse si	de.	7. If Unit or CA/A	greement, Name and/or No.	
Type of Well	8. Well Name and I GALLEGOS C	No. ANYON UNIT 228				
2. Name of Operator	9. API Well No.					
AMOCO PRODUCTION COM		30-045-11625				
3a. Address P.O. BOX 3092 HOUSTON, TX 77079	3b. Phone No. (mclude Ph: 281.366.4081 Fx: 281.366.0700	arganoode)	10. Field and Pool BASIN DAK			
4. Location of Well (Footage, Sec., T	., R., M., or Survey Description)			11. County or Pari	11. County or Parish, and State	
Sec 21 T28N R12W SWSW 7	SAN JUAN C	COUNTY, NM				
12. CHECK APPI	ROPRIATE BOX(ES) TO	INDICATE NATU	RE OF NOTICE, F	EPORT, OR OTI	HER DATA	
TYPE OF SUBMISSION			TYPE OF ACTION			
Notice of Intent	☐ Acidize	☐ Deepen	☐ Produc	tion (Start/Resume)	☐ Water Shut-Off	
_	☐ Alter Casing	☐ Fracture Tre	at 🔲 Reclar	nation	☐ Well Integrity	
☐ Subsequent Report	□ Casing Repair	☐ New Constr	iction	plete	☐ Other	
☐ Final Abandonment Notice	☐ Change Plans	Plug and Ab	andon 🔲 Tempo	rarily Abandon		
:	☐ Convert to Injection	□ Plug Back	□ Water	Disposal		
following completion of the involved testing has been completed. Final At determined that the site is ready for from 3/12/2001 Amoco Product well pending our well by well reproduction status either in the possible reserves. That reques the have completed the well replease accept our request to the status of t	pandonment Notices shall be file inal inspection.) ion Company requested p eview to determine if an a he existing zone or uphole est was approved 3/29/200 eview and find no further p	ermission to continu ttempt could be made and avoid prematur ontential exists for th	ents, including reclamations, including reclamations the shut-in status le to restore well bare abandonment of its well.	on, have been complete of this	ed, and the operator has	
14. I hereby certify that the foregoing is	Electronic Submission #	10154 verified by the				
N (D. 187   18 OHESS)	C(I)	1/	J			
Namc (Printed/Typed) CHERRY	HLAVA SWITY9	Title Title	SUBMITTING COL	NTACT		
Signature (Electronic S	Submission)	Date	01/22/2002			
	THIS SPACE FO	R FEDERAL OR	STATE OFFICE U	ISE		
Approved By		Titl	PE	Dat	c 2/8/0L	
Conditions of approval, if any, are attache certify that the applicant holds legal or equipment would entitle the applicant to conduction	nitable title to those rights in the act operations thereon.	subject lease Offi				
Title 18 U.S.C. Section 1001 and Title 43	U.S.C. Section 1212, make it a	crime for any person know	wingly and willfully to n	nake to any department	t or agency of the United	

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

## San Juan Basin Well Work Procedure

Date: Budget:	<b>1/22/2002</b> DRA				
Repair Type:	Plug and abando	nment			
Objectives:					
1. P&A enti	re wellbore.				
D. C					
Pertinent Info Location:	rmation: Sec 21 T28N R12W		Horizon:	Basin Dakota	
County:	San Juan		API#:	30-045-11625	
State: Lease:	New Mexico		Engr: Phone:	Allen Kutch (281)366-7955	
20000.			T HOHO.	(201)000 1000	
Formation To	ps: (Estimated formation to	ps)	<u>,</u>	<del>-</del>	_
Nacimento: Ojo Alamo:		Menefe Point Lo	•		
Kirtland Shale	· ·	Mancos			
Fruitland:	. 4040	Gallup:	4945		
Pictured Cliffs Lewis Shale:	: 1810	Granero Dakota:			
Chacra:		Morriso			
Cliff House:	2880				
Bradenhead	Test Information:				
Test Date:	Tubing:	Casin	g: BH:	:	
Time BH	CSG	INT (	CSG		
5 min					
10 min 15 min					

Comments:

Well Name:

Version:

GCU 228


#1

## Plug and abandonment procedure GCU 228

- 1. Contact Federal and State agencies prior to starting P&A work (NMOCD Charlie Perrin, 505-334-6178 X16, BLM 505-599-8907).
- 2. Check location for anchors. Install if necessary. Test anchors.
- 3. MIRUSU. Check and record tubing, casing and bradenhead pressures.
- 4. Blow down well and kill well, if necessary, with lease water.
- 5. ND wellhead. NU BOP's.
- 6. POOH with 2-3/8" tbg, visually inspecting.
- TIH with CIBP on tbg. Set CIBP at 5800' to abandon the DK perfs. 7.
- 8. Spot 12 sack cmt plug 5650' - 5800' to isolate the DK.
- 9. Spot 12 sack cmt plug 4800' - 4950' to isolate the GP.
- 10. Spot 12 sack cmt plug 2750' - 2900' to isolate the MV.
- 11. Spot 19 sack cmt plug 1575' - 1825' to isolate the PC / Fruitland.
- 12. Spot 12 sack cmt plug 250' - 400' to isolate the Ojo Alamo.
- 13. Spot 12 sack cmt surface plug 0 – 150'.
- 14. ND BOP. Cut off wellhead and casing. Weld on 1/4" steel plate and PXA marker.
- 15. Provide workorder to Buddy Shaw for surface reclamation.

GCU 228 - Proposed P&A Configuration San Juan County, NM Unit M Section 21 T28N - R12W Run 24

1-22-2002 ATK



PBTD: 6008' TD: 6042'