Submit 3 Copies to Appropriate District Office

CONDITIONS OF APPROVAL, IF ANY:

## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

District Office	_		
<u>DISTRICT I</u> P.O. Box 1980, Hobbs NM 88241-1980	OIL CONSERVATIO		WELL API NO.
DISTRICT II	Santa Fe, NM		30-039-07640
P.O. Drawer DD, Artesia, NM 88210		) CD /S Figures	5. Indicate Type of Lease STATE FEE X
DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410	्र <sup>(</sup> 'स	/eceive	16 (State Oil & Gas Lease No.
	CES AND REPORTS ON WEL		
(DO NOT USE THIS FORM FOR PRO DIFFERENT RESER (FORM C-	POSALS TO DRILL OR TO DEEPEN VOIR. USE "APPLICATION FOR PER 101) FOR SUCH PROPOSALS.) $\begin{pmatrix} 0 \end{pmatrix}$	OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name
1. Type of Well: OIL GAS WELL GAS WELL X	OTHER	DIST. 3	San Juan 29-6 Unit
2. Name of Operator			8. Well No.
Phillips Petroleum Company  3. Address of Operator			SJ 29-6 Unit #11 9. Pool name or Wildcat
5525 Highway 64, NBU 3004, Fa	armington NM 87401		Blanco Mesaverde
4. Well Location Unit Letter M : 850	Feet From The South	Line and 850	)' Feet From The West Line
7	2011	CI.	Dia Amila
Section /	Township 29N Ra		NMPM Rio Arriba County  J)
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF IN	· -	1	SEQUENT REPORT OF:
	TENTION TO.	308	SEGGENT REPORT OF.
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS L	COMMENCE DRILLING	OPNS. U PLUG AND ABANDONMENT U
PULL OR ALTER CASING	_	CASING TEST AND CE	MENT JOB U
OTHER: Add pay and stimulate	X	OTHER:	
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.			
MIRU. ND WH & NU BOPs. POOH w/production tubing. Isolate existing Mesaverde perfs with bridge plug. PT casing. If casing fails test - isolate failure. Remediate with cement.			
If well records indicate no cement across the Lewis Shale interval, it may be necessary to run a casing bond log (CBL). Shoot squeeze holes in casing and pump sufficient volumes of cement to cover and isolate the Lewis Shale.			
Perforate and stimulate the Lewis Shale (perfs to be determined after logs are run). Retrieve bridge plug and run production tubing. Flow test the Lewis Shale.			
A workover pit may be required.			
_			
I hereby certify that the information above is tru	e and complete to the best of my knowledge	e and belief.	
SIGNATURE Talsy	Megh m	Regulatory A	Assistant DATE 3-4-99
TYPE OR PRINT NAME Patsy (	Clugston		TELEPHONE NO. 505-599-3454
(This space for State Use)			
TRIGINAL SIGNED BY	ERNIE BUSCH	DEPUTY OIL & GAS IN	ISPECTOR, DIST. #3 MAR 15 1999