	/
NO. OF COPIES RECEIVED 3	Form C-103
DISTRIBUTION	Supersedes Old C-102 and C-103
SANTA FE NEW MEXICO OIL CONSERVATION CONSERVATION ON SEIGHT	Effective 1-1-65
FILE / NLULI I LD	
U.S.G.S.	5a. Indicate Type of Lease
LAND OFFICE AUG 6 1970	State Federal Fee.
OPERATOR /	5. State Oil & Gas Lease No.
OIL CON. COM.	
SUNDRY NOTICES AND REPORTS ON WELLS SENT 3 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL GAS X OTHER-	7. Unit Agreement Name San Juan 29-7 Unit 8. Farm or Lease Name
2. Name of Operator El Paso Natural Gas Company	San Juan 29-7 Unit
Box 990, Farmington, New Mexico 87401	9. Well No. 89 (OWWO)
4. Location of Well UNIT LETTER K 1650 FEET FROM THE South LINE AND 1450 FEET FROM	10. Field and Pool, or Wildcat Blanco Mesa Verde
UNIT LETTER R , 1000 FEET FROM THE DOUGH LINE AND 1900 FEET FROM	
THE West LINE, SECTION 7 TOWNSHIP 29N RANGE 7W NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 6302° GL	12. County Rio Arriba
Check Appropriate Box To Indicate Nature of Notice, Report or Oth	vor Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
PULL OR ALTER CASING CHANGE PLANS CASING TEST AND CEMENT JQB	
Squeeze, Case Cement, Perf & S/W Frac 🛪	
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including work) SEE RULE 1703.	estimated date of starting any proposed
In order to increase production it is planned to workover and x restimulate this well in the following manner:	
Pull tubing, set a drillable bridge plug near the bottom of the 7" casing & pressure test to 1000 psi.	
If tubing is stuck, cut off tubing approximately 100 below the 7" casing shoe, set a drillable cement retainer near the bottom of the 7" casing, squeeze the open hole w/approximately 200 sks. of cement.	
Pressure test the 7" casing to 1000 psi.	
· · ·	
Isolate and xmm squeeze cement any leaks. If leaks are squeezed near the base of the Ojo Alamo formation no additional block squeeze of the 7" annulus is planned.	
If there are no leaks near the base of the Ojo Alamos formation perforate 2 squeeze holes at the base	
of the Ojo Alamo formation & black squeeze the 7" annulus w/approximately 125 sacks of cement.	
Clean out if hole conditions permit, otherwise sidetrack and redrill to approximately 5480'.	
Run a full string of 4 1/2" production casing & sufficient amount of cement to tie into the 7" casing shoe.	
Selectively perforate & sand-water fracture the Mesa Verde formation.	
18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
Original Signed F. H. W000 Petroleum Engineer	7-31-70
6 00 1 0 0:=	\$ 1.7
APPROVED BY CELLULY (WILL) TITLE Sup from 111	DATE 0-6/0
APPROVED BY ESSENCE ANY: Petroleum Engineer TITLE Petroleum Engineer TITLE Sup Pari III	
<u>-</u>	