

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other Natural Gas Stimulation Experiment PS Reentry

2. NAME OF OPERATOR
U. S. Dept. of Energy/El Paso Natural Gas Co.

3. ADDRESS OF OPERATOR
U.S. DOE, P.O. Box 14100, Las Vegas, NV 89114

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
1218' FSL, 2070' FWL, Sec. 36, T-29-N, R-4-W
AT SURFACE: R-4-W
AT TOP PROD. INTERVAL: 3678' TVD 15.14' N, 17.14' E of surface
AT TOTAL DEPTH: At 4600' MD, 4590.69' TVD, 38.54' S & 76.15' W of surface.

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>

(other) _____

5. LEASE SF. 079761
Carson National Forest

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.
GB-2RS

10. FIELD OR WILDCAT NAME
Choza Mesa Pictured Cliffs

11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 36, T-29-N, R-4-W

12. COUNTY OR PARISH | 13. STATE
Rio Arriba | New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
KDB-7212', DF-7211', GL-7199'

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Kill well by pumping water down tubing and 7" annulus.
2. Nipple up annular BOP and tubing stripper on tubing head.
3. Pull 2-3/8" tubing, keeping hole full of water. Inspect tubing.
4. Go in hole with 2-3/8" tubing and spot a continuous cement plug from Total Depth (top of fill at 4520') to 3400'. Tag top of plug with tubing.
5. Circulate hole to surface with water.
6. Spot a cement plug inside 7" casing from 600' to 350' (55 ft³ of cement). Tag the top of the plug with tubing.
7. Spot a surface plug inside 7" casing from 15' to bottom of cellar.
8. Nipple down annular BOP and tubing stripper, remove tubing head.
9. Install a 4.0" O.D. pipe for well marker extending from 6' below ground level to 4' above ground level with top orange peeled and welded closed. Well name will be inscribed using a welded bead.
10. Cut the 9-5/8" and 7" casing strings at the bottom of cellar, backfill the cellar with dirt.

NOTE: Above operations are expected to be accomplished between 8-7-78 & 8-19-78.
Subsurface Safety Valve: Manu. and Type _____ Set @ _____ ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Dir., E&FA Div. DATE June 12, 1978

(This space for Federal or State Office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY.

APPROVED
JUN 29 1978
E. A. SCHWIDT
ACTING DISTRICT ENGINEER

RECEIVED
JUL 3 1978
OIL CON. COM.
@ DIST. 3

RECEIVED
JUN 19 1978
U. S. GEOLOGICAL SURVEY
DURANGO, COLO.

*See Instructions on Reverse Side

WELL NO. G8-2 RS
PRESENT CONDITIONS

DEPTH (FT)

0 = GROUND LEVEL




FIGURE 6

5000 —

WELL NO. GB-2RS PROPOSED ABANDONMENT

