

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT - " for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Phillips Petroleum Company

3. Address and Telephone No.

5525 Highway 64, NBU 3004, Farmington, NM 87401

505-599-3454

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit A, 907' FNL & 1253' FEL  
Section 27, T29N, R6W

5. Lease Designation and Serial No.

SF-080377

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

San Juan 29-6 Unit

8. Well Name and No.

SJ 29-6 #264

9. API Well No.

30-039-25535

10. Field and Pool, or exploratory Area

Basin Fruitland Coal

11. County or Parish, State

Rio Arriba, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other Cover cmt- Nacimiento

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Purpose of Job: Squeeze cement across the Nacimiento (top @ 1310') to meet BLM requirements. Verbal approval was received @ 3:15 PM 11/7/95, from Errol Becher to perform the following:

1. ND and NU BOP.
2. TOH w/2-3/8" production tubing.
3. RIH w/RBP and set @ +/- 1600'. Spot 1 sx sand on RBP. Load hole with CS produced H2O.
4. RIH & Perforate 1500' w/4 spf (.35" holes).
5. RIH w/treating packer & set @ 1300'. Test backside to 1000 psi.
6. Pump +/- 350 sx Class "G" cement w/2% CaCl2 (until cement returns at surface) followed by 6 bbls CS produced water.
7. WOC 12 hours. Release packer & POOH.
8. RIH w/3-7/8" bit and drill out cement and GIH to top of sand on RBP. Test squeeze to 1000 psi. POOH w/bit.
9. RIH and circulate sand off RBP w/CS produced water. Release and retrieve RBP.
10. RIH and set production tubing to +/- 3,300' KB.
11. ND BOP & install X-Mas tree. PT to 3000 psi.
12. Swab well if necessary. RD & release rig.

14. I hereby certify that the foregoing is true and correct

Signed

*Ed Harsely*

Title Envir./Regulatory Engineer

Date 11-8-95

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\* See Instruction on Reverse Side

NMOCD

DISTRICT MANAGER

APPROVED

NOV 27 1995