## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Notices an	d Reports on Wells		
		5.	Lease Number SF-078503
1. Type of Well GAS		6.	If Indian, All. or Tribe Name
		7.	Unit Agreement Name
2. Name of Operator			San Juan 29-7 Unit
$BURLINGTON \ RESOURCES _ { text{0IL & GAS}} C$	OMPANY		
		8.	Well Name & Number
3. Address & Phone No. of Operator			San Juan 29-7 U #109
PO Box 4289, Farmington, NM 87499 (505) 326-9700		9.	<b>API Well No.</b> 30-039-21330
4. Location of Well, Footage, Sec., T, R, M 1190' FNL, 790' FEL, Sec. 30, T-29-N, R-7-W, NMPM			<b>Field and Pool</b> Basin Dakota
	.,,,	11.	County and State Rio Arriba Co, NM
Subsequent Report P Final Abandonment A	ecompletion Number Numb	hange of Place ew Construction-Routine Cater Shut of Conversion to	tion Fracturing ff
13. Describe Proposed or Completed O	perations		<del></del>
It is intended to repair the tub attached procedure.	ing on the subject w	ell accordi	ng to the
	EGEIVED JUN 1 3 1898 DIL GOIGH DORW		RECEIVERS 3: 98 JULI 11 FI 3:
14. I hereby certify that the forego	ing is true and corr	ect	2 2
$\chi$			ata 6/5/00
Signed MANA MANA LILE (LTL8) T	itle <u>Requlatory Admi</u>	<u>nistrator</u> D VK	
(This space for Federal or State Office APPROVED BY STATE BY STAE BY STATE	e use) Title	Date J	IN 1 7 1998
CONDITION OF APPROVAL, if any:		_	

## San Juan 29-7 Unit #109

## Basin Dakota

Unit A, Sec. 30, T-29-N, R-7-W

Latitude / Longitude: 36°42.06210' / 107°36.33726' Recommended Tubing Repair Procedure 5/20/98

NOTE: ALL DEPTHS ARE MEASURED FROM KB. KB to GL was 10'.

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Prior to moving in rig, make one-call and then verify rig anchors and dig pit.
- MIRU workover rig. NU relief line and blow well down (kill with 2% KCL water only if necessary). ND WH and NU BOP. Test and record operation of BOP rams. Replace any WH valves that do not operate properly. Test secondary seal and install or replace if necessary.
- 3. Dakota, 1-1/2", 2.9#, V-55 tubing set at 7535'. Broach tubing and set tubing plug in nipple at 7504'. Fill tubing with half of its volume of 2% KCL to insure the tubing plug will be held in place. Release donut, pick up additional joints of tubing and tag bottom, recording the depth. PBTD should be at +/- 7646'. TOOH and LD 1-1/2" tubing. Visually inspect tubing for corrosion, and replace any bad joints. Check tubing for scale and notify Operations Engineer if it is present.
- 4. PU & TIH with 3-7/8" bit, bit sub, and watermelon mill on 2-3/8", 4.7#, J-55 Class "B" tubing and round trip to PBTD, cleaning out with air/mist. NOTE: When using air/mist, mist rate must not be less than 12 bph. Speak with Operations Engineer, and if necessary, determine the best way to remove scale from the casing and perforations.
- 5. TIH with one joint of 2-3/8", 4.7#, J-55 Class "B" tubing with expendable check, F-nipple (one joint off bottom), then ½ of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist.
- 6. PU above the top Dakota perforation at **7390'** and flow the well naturally, making short trips for clean-up when necessary. Obtain pitot gauge from casing and report this gauge after final clean-up.
- 7. Land tubing at **7535**'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. If well will not flow on its own, make swab run to SN. RD and MOL. Return well to production.

Recommended: John Jovel Approved: Bruce D. Boys 6-1-98
Operations Engineer 5/20/98

Drilling Superintendent

<u>Contact:</u> L. Tom Loveland Office 326-9771

Pager 324-2568 Home 564-4418