

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name San Juan 30-4 Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name San Juan 30-4 Unit
3. Address of Operator PO Box 990, Farmington, NM 87401	9. Well No. 2 (P&A)
4. Location of Well UNIT LETTER <u>A</u> <u>667</u> FEET FROM THE <u>North</u> LINE AND <u>833</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>30N</u> RANGE <u>4W</u> NMPM.	10. Field and Pool, or Wildcat East Blanco Pictured Cl.
15. Elevation (Show whether DF, RT, GR, etc.) 7512'GL	12. County Rio Arriba

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production, it is planned to plug and abandon this well in the following manner:

Spot a 50 sack cement plug to fill to 4033' and cover perforations (4248-4300').

Perforate squeeze holes in 7" casing at 3813' (base of Ojo Alamo). Spot a 50 sack cement plug at 3813' and pressure displace 25 sacks to cover Ojo Alamo outside casing and leave 25 sacks inside the casing to cover the Ojo Alamo.

Shoot off 7" casing at free point and pull casing. Spot a 50 sack cement plug on the casing stub.

Spot a 25 sack cement plug at base of the 9 5/8" surface casing.

Spot a 15 sack cement plug at the surface with a Plug & Abandon marker, clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed F. H. WOOD

SIGNED

TITLE Petroleum Engineer

DATE October 14, 1971

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

