

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-079012

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

San Juan 31-6 Unit

8. FARM OR LEASE NAME

San Juan 31-6 Unit

9. WELL NO.

4

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 4, T³⁰N, R6W, NMPM

12. COUNTY OR PARISH

Rio Arriba

13. STATE

New Mexico

1. OIL ☐ WELL GAS ☒ WELL OTHER

2. NAME OF OPERATOR

Northwest Pipeline Corporation

3. ADDRESS OF OPERATOR

P.o. Box 90 Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

990' FNL - 990' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6451' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Because of non production, it is planned to plug & abandon this well as follows:

Pull or cut off tubing, spot a 125 sack cement plug in open hole, pull remainder of tubing.

Determine free point of 7" casing by stretch method. If freepoint is in the Ojo Alamo shoot casing off above free point and spot a 50 sack cement plug on casing stub. If freepoint is above the Ojo Alamo, perforate 4 squeeze holes at base of Ojo Alamo and spot 100 sacks cement, squeeze, cut casing off above free point and spot 50 sack cement plug on casing stub. Retrieve casing.

Spot 25 sack cement plug in base of surface casing.

Place a 15 sack cement plug at the surface and install a 4"x 4' dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED R.E. Fielder

TITLE Production Engineer

DATE December 23, 1974

R.E. Fielder js

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side