

5 BLM 1 File

Form 3160-5
(November 1983)
(Formerly 9-331)UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENTSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. SF-078931-B (CA#8561)
2. NAME OF OPERATOR DUGAN PRODUCTION CORP.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 420, Farmington, NM 87499		7. UNIT AGREEMENT NAME Central Cha Cha Unit
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 510' FSL & 1980' FEL		8. FARM OR LEASE NAME Central Cha Cha Unit
14. PERMIT NO.		9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5935' GL; 5946' RKB		10. FIELD AND POOL, OR WILDCAT Cha Cha Gallup
		11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA Sec. 31, T29N, R13W, NMPM
		12. COUNTY OR PARISH San Juan
		13. STATE NM

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐PULL OR ALTER CASING ☐WATER SHUT-OFF ☐REPAIRING WELL ☐FRACTURE TREAT ☐MULTIPLE COMPLETE ☐FRACTURE TREATMENT ☐ALTERING CASING ☐SHOOT OR ACIDIZE ☐ABANDON* ☐SHOOTING OR ACIDIZING ☐ABANDONMENT* ☐REPAIR WELL ☐CHANGE PLANS ☐(Other) ☐(Other) Revised Plugging Procedure ☒

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1.) Due to unrecoverable junk in hole, we plan to set 4-1/2" cement retainer as deep as possible - 3400' plus.
- 2.) Pump 50 sacks class "B" below retainer.
- 3.) Perf casing @ 3165' and place 100' class "B" cement plug inside and outside 4-1/2" casing.
- 4.) Perf casing 2525'. Place 100' cement plug inside and outside 4-1/2" casing.
- 5.) Spot 100' class "B" cement plug 1605'-1505' inside 4-1/2" casing.
- 6.) Perf casing @ 1282' and place 100' cement plug inside and outside casing.
- 7.) Place cement plug 260' to surface inside and outside casing.
- 8.) Cut off wellhead and install dry hole marker.

Note: This procedure discussed with Mr. Ken Townsend.

18. I hereby certify that the foregoing is true and correct

SIGNED

Jim L. Jacobs

TITLE

Geologist

DATE

7-12-89

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

NMOC

APPROVED

DATE

Townsend