Form	3160-5
(June	1990)

TYPE OF SUBMISSION

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

	SF.	07906	5
6.	If Indian	. Allottee or	Tribe Name

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals

Notice of Intent

Abandonment

Recompletion

Plugging Back

Casing Repair

Final Abandonment Notice

Abandonment

Change of Plans

New Construction

Non-Routine Fracturing

Water Shut-Off

Altering Casing

Conversion to Injection

Altering Casing Conversion to Injection

Other Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

as (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drille

TYPE OF ACTION

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

See attached Report for Pak

DECEVED MAY 2 6 1938

OIL COM. DIV.

14. I hereby certify that the foregoing is true and correct

Signed NMOCO CONTINCT

Title

Date 5/21/98

(This space for Federal or State office use)

Approved by Symme W. Symmer

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

TRIPLE P WELL SERVICE, INC.

AZTEC TOTAH #10 RIG 6 START 3/23/98 END 3/24/98

- 1. Pull and laydown 197 rods.
- 2. Cut tubing @ 4986'. Pull and laydown 160 joints +-5000'.
- 3. Run in hole, set cement retainer @ 4914'. Mix and pump 25sx, 29.5cf.
- 4. Perforate 4 squeeze holes @ 2728'. Run in hole with cement retainer set @ 2646'. Mix and pump 55sx, 64.9cf cement.
- 5. Displace and balance 35sx, 41.3cf @ 1141' cement top @ 630'.
- 6. Shoot 4 squeeze holes @ 249'. Could not establish circulation. Shoot 4 squeeze holes @ 180'. Circulate cement to surface. 85sx, 100cf.