## UNITED STATES DEPARTMENT OF THE INTERIOR

UNITED STATES	5. LEASE -0603
DEPARTMENT OF THE INTERIOR	14-20 <del>-2603-</del> 7106
GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
	Navajo Tribal
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT NAME
(Do not use this form for proposals to drill or to deepen or plug back to a different	# £ # # 1
reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME 👙 ಲಕ್ಷಿಕ್ಕ
1. oil gas	Waterflow San
well well other	9. WELL NO.
2. NAME OF OPERATOR	2 ខ្លាំង មួន មួន
J. Gregory Merrion	10. FIELD OR WILDCAT NAME
3. ADDRESS OF OPERATOR	So. Waterflow Gallup
P. O. Box 507, Farmington, NM, 87401	11. SEC., T., R., M., OR BLK. AND SURVEY O
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA L. of A beroa
below.)	Sec. 20, T29N, R15W
AT SURFACE: 660' FNL & 660' FWL	12. COUNTY OR PARISH 13. STATE
AT TOP PROD. INTERVAL:	San Juan - New Mexic
AT TOTAL DEPTH:	14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD
	13. ELECTIONS ISHOW DF, KDB, AND WD
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	
FRACTURE TREAT	
SHOOT OR ACIDIZE	X = X = X
BILL OR ALTER CASING III	(NOTE: Report results of multiple completion or zon
MILITIPLE COMPLETE III III III III III III III III III	change of Form 9-1300
Change Zunes 11 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	100 V 100 1
CHANGE ZONES	DIST COM
(other)	
17 DECORUPE PROPOSED OR COURT TIES	
I/ DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Classic state	
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state including estimated date of starting any proposed work. If well is di	rootionally deillad -t., a., b., 1
including estimated date of starting any proposed work. If well is di measured and true vertical depths for all markers and zones pertinent	rootionally deillad -t., a., b., 1
INCHAIND ESTIMATED DATE OF STARTING ANY PROPOSED WORK. If well is di	rootionally deillad -t., a., b., 1
measured and true vertical depths for all markers and zones pertinent	irectionally drilled, give subsurface locations and t to this work.)*
INCHAIND ESTIMATED DATE OF STARTING ANY PROPOSED WORK. If well is di	irectionally drilled, give subsurface locations and t to this work.)*
measured and true vertical depths for all markers and zones pertinent  Pull rods. Spot cement 4258 - 4150. (8	irectionally drilled, give subsurface locations and t to this work.)*
measured and true vertical depths for all markers and zones pertinent	irectionally drilled, give subsurface locations and t to this work.)*
Pull tubing.	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  3 sacks)
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Po	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  3 sacks)  4 3900 - 3800 (15 sacks)
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across top spot 25 sacks cement plug across top	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  3900 - 3800 (15 sacks)  oint Lookout 2680 - 2580 (150)  op of Cliffhouse 1630 - 1530
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bo	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3900 - 3800 (15 sacks)  pint Lookout 2680 - 2580 500 por Cliffhouse -1630 - 1530 500 500 ttom of surface csg 256-156.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across top spot 25 sacks cement plug across top	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3900 - 3800 (15 sacks)  pint Lookout 2680 - 2580 500 por Cliffhouse -1630 - 1530 500 500 ttom of surface csg 256-156.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bo	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3900 - 3800 (15 sacks)  pint Lookout 2680 - 2580 500 por Cliffhouse -1630 - 1530 500 500 ttom of surface csg 256-156.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bo	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3900 - 3800 (15 sacks)  pint Lookout 2680 - 2580 500 por Cliffhouse -1630 - 1530 500 500 ttom of surface csg 256-156.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across both Put 10 foot plug in surface. Erect	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  9 of Cliffhouse 1530 1530.  9 of Surface Cosq 256-156.  9 marker.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bo	sacks)  3 sacks)  3 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  9 sacks)  9 sacks)  9 sacks)  10 sacks)
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bo Put 10 foot plug in surface. Erect	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  9 of Cliffhouse 1530 1530.  9 of Surface Cosq 256-156.  9 marker.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bor Put 10 foot plug in surface. Erect Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct	sacks)  3 sacks)  3 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  9 sacks)  9 sacks)  9 sacks)  10 sacks)
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across bor Put 10 foot plug in surface. Erect  Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  9 of Cliffhouse 1530 1530.  9 of Surface Cosq 256-156.  9 marker.
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across book Put 10 foot plug in surface. Erect Subsurface Safety Valve: Manu. and Type  18. I hereby cartify that the foregoing is true and correct SIGNED	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 int Lookout 2680 - 2580 - 1530 - 2580 to marker.  Set marker.  DATE March 20, 1981
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across be Put 10 foot plug in surface. Erect  Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct  SIGNED  TITLE Owner	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 int Lookout 2680 - 2580 - 1530 - 2580 to marker.  Set marker.  DATE March 20, 1981
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across be Put 10 foot plug in surface. Erect  Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct  SIGNED	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 int Lookout 2680 - 2580 - 1530 - 2580 to marker.  Set marker.  DATE March 20, 1981
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across be Put 10 foot plug in surface. Erect Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct SIGNED  TITLE Owner	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 solution of cliffhouse 1630 - 1530.  7 set marker.  8 pare March 20, 1981
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across be Put 10 foot plug in surface. Erect Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct SIGNED TITLE Owner  (This space for Federal or State office APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  7 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  8 sacks)  9 of Cliffhouse 1630 1530.  9 of Cliffhouse 256-156.  9 marker.  8 sacks  9 of Cliffhouse 1630 1530.  1 sacks  1
Pull rods. Spot cement 4258 - 4150. (8  Pull tubing.  Shoot off csg at 3850. Spot cement Spot 25 sacks plug across top of Pospot 25 sacks cement plug across to Spot 30 sacks cement plug across be Put 10 foot plug in surface. Erect  Subsurface Safety Valve: Manu. and Type  18. I hereby certify that the foregoing is true and correct  SIGNED	irectionally drilled, give subsurface locations and to this work.)*  3 sacks)  3 sacks)  5 sacks)  6 15 sacks)  6 15 sacks)  7 sacks)  7 sacks)  7 sacks)  7 sacks)  7 sacks)  8 sacks)  8 sacks)  8 sacks)  9 of Cliffhouse 1630 1530.  9 of Cliffhouse 256-156.  9 marker.  8 sacks  9 of Cliffhouse 1630 1530.  1 sacks  1

\*See Instructions on Reverse Side

DISTRICT OIL & GAS SUPERVISOR