

GOVERNOR

STATE OF NEW MEXICO

ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION AZTEC DISTRICT OFFICE

1000 RIO BRAZOS PDAD AZTEC, NEW MEXICO 87410 (505) 334-6178

DIVISION APPROVED PLUGGING PROGRAM

J. Warren Miller
Culpepper #1
694' FSL, 996' FWL
M-16-T29N-R13W, San Juan County, N.M.

Downhole Equipment
Unknown
T.D. 1285' presumed

- 1. Locate well.
- 2. Enter hole and clean out/or drill to 1285'.
- 3. If hole is cased set a cement plug from T.D. to 850', inside and outside the casing, to isolate Pictured Cliffs formation.
- 4. If hole is not cased set a cement plug from T.D. to 850', to isolate Pictured Cliffs formation.
- 5. Refer to step #3 and set a cement plug from 400' surface inside and outside, to isolate Farmington S.S.
- 6. Refer to step #4 and set a plug from 400' to surface, to isolate Farmington S.S.
- 7. Set dry hole marker.
- 8. Clean and restore location to original condition.
- 9. All plugs shall be of Class A, B, or C neat cement and may be accelerated by up to 3% CaCl₂.
- 10. All plugs are to be separated by gel mud of minimum nine pounds per gallon.